

# Instruction Manual

## COMMERCIAL GAS WATER HEATERS



GAS-FIRED



WATER QUALITY



MODELS 750A & 1000A  
SERIES 100 & 101  
INSTALLATION - OPERATION  
- SERVICE - MAINTENANCE



**WARNING:** If the information in these instructions is not followed exactly, a fire or explosion may result causing property damage, personal injury or death.

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- **WHAT TO DO IF YOU SMELL GAS:**
  - Do not try to light any appliance.
  - Do not touch any electrical switch; do not use any phone in your building.
  - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
  - If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency or the gas supplier.

Thank you for buying this energy efficient water heater. We appreciate your confidence in our products.

### **WARNING**



Read and understand this instruction manual and the safety messages herein before installing, operating or servicing this water heater.

Failure to follow these instructions and safety messages could result in death or serious injury.

This manual must remain with the water heater.

ALL TECHNICAL AND WARRANTY QUESTIONS SHOULD BE DIRECTED TO THE LOCAL DEALER FROM WHOM THE WATER HEATER WAS PURCHASED. IF YOU ARE UNSUCCESSFUL, CALL THE TECHNICAL SUPPORT PHONE NUMBER SHOWN ON THE WATER HEATER LABELING.

KEEP THIS MANUAL IN THE POCKET ON HEATER FOR FUTURE REFERENCE WHENEVER MAINTENANCE ADJUSTMENT OR SERVICE IS REQUIRED.

# CONTENTS


SAFE INSTALLATION, USE, AND SERVICE .....	3	AL29-4C® Vent Installations .....	26
APPROVALS .....	3	Venting Arrangements .....	27
GENERAL SAFETY INFORMATION .....	4	Termination Clearances Sidewall Power Vent .....	28
Precautions .....	4	Termination Clearances Sidewall Direct Vent .....	29
Grounding Instructions .....	4	WATER HEATER INSTALLATION .....	30
Hydrogen Gas Flammable .....	4	Condensate Drain Installation .....	30
INTRODUCTION .....	6	Supply Gas Line Installation .....	30
Abbreviations Used .....	6	Purging .....	32
Qualifications .....	6	Electrical Wiring .....	32
ICOMM .....	6	TEMPERATURE REGULATION .....	35
ICC .....	6	High Temperature Limit Control (ECO) .....	35
Preparing for the Installation .....	6	Thermostat Control .....	35
FEATURES AND COMPONENTS .....	8	Intelligent Demand Response .....	35
Basic Operation .....	8	Firing Rate Modulation .....	35
Modulation .....	8	CONTROL SYSTEM OPERATION .....	36
Components .....	8	Overview .....	36
INSTALLATION CONSIDERATIONS .....	10	Control System Navigation .....	36
Rough-In Dimensions .....	10	Lockout Function .....	36
Locating the Water Heater .....	11	The Desktop Screen .....	36
Hard Water .....	12	User Settings & Control System Menus .....	39
Circulation Pumps .....	12	START UP .....	48
INSTALLATION REQUIREMENTS .....	13	Prior to Start up .....	48
Supply Gas Line Requirements .....	13	Checking the Firing Rate .....	50
Supply Gas Regulator .....	13	High Altitude Installations .....	51
Power Supply .....	13	TROUBLESHOOTING .....	52
Mixing Valves .....	13	Installation Checklist .....	52
Dish-washing Machines .....	14	Sequence of Operation .....	52
Closed Water Systems .....	14	Sequence of Operation Flow Chart .....	53
Thermal Expansion .....	14	Operational Problems .....	54
Temperature-Pressure Relief Valve .....	15	Fault and Alert Conditions .....	55
Condensate Drain .....	16	MAINTENANCE .....	58
Combustible Material Storage .....	16	General .....	58
Contaminated Air .....	16	Maintenance Schedule .....	58
Air Requirements .....	17	Draining and Flushing .....	58
Confined Space .....	17	Sediment Removal .....	59
VENTING INSTALLATION .....	20	Lime Scale Removal .....	59
General Venting Information .....	20	Burner Flame Inspection .....	60
General Venting Instructions .....	20	Powered Anodes Maintenance .....	60
Venting Requirements .....	21	Temperature-Pressure Relief Valve Test .....	61
Venting Installation Sequence .....	22	Vent System Maintenance .....	61
Power Vent Installation .....	22	DIAGRAMS .....	62
Direct Vent Installation .....	22	CCB - Central Control Board Layout .....	62
Direct Vent Air Intake Moisture Protection .....	23	Wiring Diagram .....	63
Vertical Termination Installation .....	23	Circulation Pump Wiring Diagrams .....	64
Polypropylene Installations .....	26	Water Piping Diagrams .....	65





# SAFE INSTALLATION, USE, AND SERVICE

The proper installation, use and servicing of this water heater is extremely important to your safety and the safety of others.

Many safety-related messages and instructions have been provided in this manual and on your own water heater to warn you and others of a potential injury hazard. Read and obey all

safety messages and instructions throughout this manual. It is very important that the meaning of each safety message is understood by you and others who install, use, or service this water heater.

	<p>This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.</p>
---	---

	<p>DANGER indicates an imminently hazardous situation which, if not avoided, will result in injury or death.</p>
	<p>WARNING indicates a potentially hazardous situation which, if not avoided, could result in injury or death.</p>
	<p>CAUTION indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury.</p>
	<p>CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, could result in property damage.</p>

All safety messages will generally tell you about the type of hazard, what can happen if you do not follow the safety message, and how to avoid the risk of injury.

## IMPORTANT DEFINITIONS

- Qualified Installer or Service Agency:**

Installation and service of this water heater requires ability equivalent to that of a Qualified Agency (as defined by ANSI below) in the field involved. Installation skills such as plumbing, electrical supply are required in addition to electrical testing skills when performing service.

- ANSI Z223.1:**

“Qualified Agency” - “Any individual, firm, corporation or company that either in person or through a representative is engaged in and is responsible for (a) the installation, testing or replacement of gas piping or (b) the connection, installation, testing, repair or servicing of appliances and equipment; that is experienced in such work; that is familiar with all precautions required; and that has complied with all the requirements of the authority having jurisdiction.”

## APPROVALS

All models are listed by Underwriters Laboratories Inc.



**Note:** ASME construction is optional on the water heaters covered in this manual.

# GENERAL SAFETY INFORMATION

## PRECAUTIONS

DO NOT USE THIS APPLIANCE IF ANY PART HAS BEEN EXPOSED TO FLOODING OR WATER DAMAGE. Immediately call a qualified service agency to inspect the appliance and to make a determination on what steps should be taken next.


If the unit is exposed to the following, do not operate heater until all corrective steps have been made by a qualified service agency.

1. External fire.
2. Damage.
3. Firing without water.

## GROUNDING INSTRUCTIONS

This water heater must be grounded in accordance with the *National Electrical Code* and/or local codes. These codes must be followed in all cases. Failure to ground this water heater properly may also cause erratic control system operation.

This water heater must be connected to a grounded metal, permanent wiring system; or an equipment grounding conductor must be run with the circuit conductors and connected to the equipment grounding terminal or lead on the water heater.

	<b>⚠ WARNING</b>
	<b>Explosion Hazard</b>
<ul style="list-style-type: none"><li>• Flammable hydrogen gases may be present.</li><li>• Keep all ignition sources away from faucet when turning on hot water.</li></ul>	


## HYDROGEN GAS FLAMMABLE

Hydrogen gas can be produced in a hot water system served by this water heater that has not been used for a long period of time (generally two weeks or more). Hydrogen gas is extremely flammable. To reduce the risk of injury under these conditions, it is recommended that a hot water faucet served by this water heater be opened for several minutes before using any electrical appliance connected to the hot water system. If hydrogen is present there will probably be an unusual sound such as air escaping through the pipe as the water begins to flow. ***There should be no smoking or open flame near the faucet at the time it is open.***

**Verify the power to the water heater is turned off before performing any service procedures. The Enable /Disable switch on front panel disables the 24 volt gas valve. Electrical supply must be turned off at circuit breaker serving water heater.**

	<b>⚠ WARNING</b>
	<p>Read and understand this instruction manual and the safety messages herein before installing, operating or servicing this water heater.</p> <p>Failure to follow these instructions and safety messages could result in death or serious injury.</p> <p>This manual must remain with the water heater.</p>

	<b>⚠ WARNING</b>
	<b>Explosion Hazard</b>
<ul style="list-style-type: none"><li>• Flammable hydrogen gases may be present.</li><li>• Keep all ignition sources away from faucet when turning on hot water.</li></ul>	

<b>⚠ DANGER</b>	<p>Water temperature over 125°F (52°C) can cause severe burns instantly resulting in severe injury or death.</p> <p>Children, the elderly and the physically or mentally disabled are at highest risk for scald injury.</p> <p>Feel water before bathing or showering.</p> <p>Temperature limiting devices such as mixing valves must be installed when required by codes and to ensure safe temperatures at fixtures.</p>
	



<b>CAUTION</b>
<b>Improper installation, use and service may result in property damage.</b>
<ul style="list-style-type: none"><li>• Do not operate water heater if exposed to flooding or water damage.</li><li>• Inspect anode rods regularly, replace if damaged.</li><li>• Install in location with drainage.</li><li>• Fill tank with water before operation.</li><li>• Properly sized thermal expansion tanks are required on all closed water systems.</li></ul> <p>Refer to this manual for installation and service.</p>

**⚠️ WARNING**

**Fire or Explosion Hazard**

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- Avoid all ignition sources if you smell gas.
- Do not expose water heater controls to excessive gas pressure.
- Use only the gas shown on the water heater rating label.
- Maintain required clearances to combustibles.
- Keep ignition sources away from faucets after extended periods of non-use.

Read instruction manual before installing, using or servicing water heater.

**⚠️ WARNING**

**Fire Hazard**




**For continued protection against the risk of fire:**

**Do not install water heater on carpeted floor.**

**Do not operate water heater if flood damaged.**

**⚠️ WARNING**

**Breathing Hazard - Carbon Monoxide Gas**




- Do not obstruct water heater air intake with insulating blanket.
- Gas and carbon monoxide detectors are available.
- Install water heater in accordance with the instruction manual.

Breathing carbon monoxide can cause brain damage or death. Always read and understand instruction manual.

**⚠️ WARNING**

**Fire and Explosion Hazard**



- Use joint compound or Teflon tape compatible with propane gas.
- Leak test gas connections before placing water heater in operation.
- Disconnect gas piping at main gas shutoff valve before leak testing heater.
- Install sediment trap in accordance with NFPA 54 or CAN/CSA B149.1.


**CAUTION**

**Property Damage Hazard**

- All water heaters eventually leak.
- Do not install without adequate drainage.

**⚠️ WARNING**


**Fire and Explosion Hazard**



- Do not use water heater with any gas other than the gas shown on the rating label.
- Excessive gas pressure to gas valve can cause serious injury or death.
- Turn off gas lines during installation.
- Contact a qualified installer or service agency for installation and service.

**⚠️ WARNING**

**Electrical Shock Hazard**





- Turn off power at the branch circuit breaker serving the water heater before performing any service.
- Label all wires prior to disconnecting when performing service. Wiring errors can cause improper and dangerous operation.
- Verify proper operation after servicing.
- Failure to follow these instructions can result in personal injury or death.

**⚠️ WARNING**

**Jumping out control circuits or components can result in property damage, personal injury or death.**

- Service should only be performed by a qualified service technician using proper test equipment.
- Altering the water heater controls and/or wiring in any way could result in permanent damage to the controls or water heater and is not covered under the limited warranty.

Any bypass or alteration of the water heater controls and/or wiring will result in voiding the appliance warranty.

# INTRODUCTION

Thank You for purchasing this water heater. Properly installed and maintained, it should give you years of trouble free service.

## ABBREVIATIONS USED

Abbreviations found in this Instruction Manual include :

- ANSI - American National Standards Institute
- ASME - American Society of Mechanical Engineers
- AHRI - Air Conditioning, Heating and Refrigeration Institute
- NEC - National Electrical Code
- NFPA - National Fire Protection Association
- UL - Underwriters Laboratory
- CSA - Canadian Standards Association

## QUALIFICATIONS

### QUALIFIED INSTALLER OR SERVICE AGENCY

Installation and service of this water heater requires ability equivalent to that of a Qualified Agency (as defined by ANSI below) in the field involved. Installation skills such as plumbing, air supply, venting, gas supply and electrical supply are required in addition to electrical testing skills when performing service.

**ANSI Z223.1:** “Qualified Agency” - “Any individual, firm, corporation or company that either in person or through a representative is engaged in and is responsible for (a) the installation, testing or replacement of gas piping or (b) the connection, installation, testing, repair or servicing of appliances and equipment; that is experienced in such work; that is familiar with all precautions required; and that has complied with all the requirements of the authority having jurisdiction.”

If you are not qualified (as defined by ANSI above) and licensed or certified as required by the authority having jurisdiction to perform a given task do not attempt to perform any of the procedures described in this manual. If you do not understand the instructions given in this manual do not attempt to perform any procedures outlined in this manual.

### iCOMM

This water heater comes equipped with the iCOMM™ remote monitoring system. It allows users to monitor critical operations and diagnose issues remotely using the manufacturer’s water heater app (available for IOS and Android).

The iCOMM™ system can automatically notify selected personnel via email and or cellular phone text messages if operational problems or user defined Alert conditions should occur. The system is expandable to meet the needs of multiple heaters and groups of heaters.

### ICC

This water heater is connectible to BACnet or Modbus compliant Supervisory controls via the ICC BMS Gateway. This allows connection of the water heater to local Building Management Systems using Serial RS-485 (MS/TP) or IP connections.

To order or to find out more about iCOMM™ or ICC devices, login to the manufacturer’s website or call 888-928-3702 (888-WATER02) for more information.

## PREPARING FOR THE INSTALLATION

1. Read the entire manual before attempting to install or operate the water heater. Pay close attention to the **General Safety Information** (page 4). If you don’t follow the safety rules, the water heater may not operate safely. It could cause property damage, injury and/or death.

This manual contains instructions for the installation, operation, and maintenance of the water heater. It also contains warnings throughout the manual that you must read and be aware of. All warnings and all instructions are essential to the proper operation of the water heater and your safety.

Detailed installation diagrams are also found in this manual. These diagrams will serve to provide the installer with a reference. It is essential that all venting, water piping, gas piping and wiring be installed as shown.

Particular attention should be given to the installation of thermometers at the locations indicated in the piping diagrams as these are necessary for checking the operation of the water heater.

The principal components of the water heater are identified in **Features and Components** (page 8) this manual. Use this reference to locate and identify various components on the water heater.

See the **Installation Checklist** and **Troubleshooting** (page 52). By using this checklist the user may be able to make minor operational adjustments and avoid unnecessary service calls. However, service and diagnostic procedures should only be performed by a Qualified Service Agency.

**Note:** Costs to correct installation errors are not covered under the limited warranty.

2. Be sure to turn off power when working on or near the electrical system of the water heater. Never touch electrical components with wet hands or when standing in water.
3. The installation must conform to all instructions contained in this manual and the local code authority having jurisdiction. These shall be carefully followed in all cases. Authorities having jurisdiction should be consulted before installation begins if there are any questions regarding compliance with local, state or national codes.

In the absence of local codes, the installation must comply with the current editions of the **National Fuel Gas Code, ANSI Z223.1/NFPA 54** and the **National Electrical Code, NFPA 70** or **CAN/CSA-B149.1**, the **Natural Gas and Propane Installation Code** and **CSA C22.1**, the **Canadian Electrical Code**. All documents are available from the Canadian Standards Association, 8501 East Pleasant Valley Road, Cleveland, OH 44131. NFPA documents are also available from the National Fire Protection Association, 1 Batterymarch Park, Quincy, MA 02269.

4. If after reading this manual you have any questions or do not understand any portion of the instructions, call the toll free number on the back cover of this manual for technical assistance. In order to expedite your request, please have the full Model, Serial and Series number of the water heater you are working with available for the technician. This information is located on the water heater’s rating label.

5. Carefully plan the placement of the water heater. Examine the location to ensure that it complies with the requirements in *Rough-In Dimensions* (page 10) and *Locating the Water Heater* (page 11).
6. For installation in California this water heater must be braced or anchored to avoid falling or moving during an earthquake. See instructions for correct installation procedures. Instructions may be obtained from California Office of the State Architect, 1102 Q Street, Suite 5100, Sacramento, CA 95811.

# FEATURES AND COMPONENTS

## BASIC OPERATION

The water heaters covered in this manual have a primary heat exchanger that is submerged in the storage tank and a secondary heat exchanger mounted below the tank. The water heater's Main Burner is a radial-design burner that is mounted on the top and fires downward through the two heat exchangers. This is a forced draft burner; hot burning gases are forced through the two heat exchangers under pressure and exit through the exhaust/vent connection located at the bottom of the water heater. See *Figure 2*.

## COMPONENTS

## MODULATION

The water heaters covered by this manual are capable of modulating their firing rate. The CCB monitors the water temperature in the tank and regulates the firing rate to achieve the target temperature setpoint. The firing rate is dictated by the hot water draw, proximity to the tank temperature setpoint, and various other temperature limitations.




Figure 1. Front View

**Important:** The Enable/Disable switch listed in this manual is NOT an “on/off” switch and does not disconnect 120 volt power to the CCB and other heater components.

1. Water Heater's Enable/Disable Switch. When in the “Disabled” position the switch removes electrical power from the gas valve so that water heating is disabled. The display, CCB, and other electrical components will still be energized




Figure 2. Blower Burner Assembly

and the display will read “Water Heating Disabled.”

2. UIM (user interface module). The UIM includes the display circuit board and the control system's LCD Touch Display. Used to adjust various user settings and view operational information.
3. Central Control Board (CCB) enclosure. This enclosure houses the control system's main circuit board, power supply board, power transformer, and configuration key. The CCB



regulates water temperature and controls all water heater functions. See **Control System Operation** (page 36).

4. 120 VAC junction box. Incoming power supply, ground connections, and other field installed electrical connections are made here. See **Power Supply** (page 13) and **Power Supply Connections** (page 32).
5. Blocked Intake Air switch. Normally closed contacts that open on fall in pressure. This switch is used to insure intake (combustion) air to the water heater is not restricted. The control system monitors this switch and will disable heating operation if its contacts are open during a heating cycle.
6. Temperature-Pressure Relief Valve. See **Temperature-Pressure Relief Valve** (page 15).
7. 1" Honeywell modulating 24 VAC gas valve.
8. 6" PVC air intake connection.
9. Honeywell Venturi Mixing Unit.
10. Combustion blower.
11. Combustion sight glass.
12. Flame Sensor: The control system also monitors the flame sensor to confirm a flame is present at the Main Burner. If a flame is not verified during the ignition trial period (3-5 seconds) the control system will immediately de-energize the 24 VAC Gas Valve. See **Sequence of Operation Flow Chart** (page 53).
13. Spark Electrode: The control system energizes the spark ignition control with 120 VAC during the ignition period. The spark ignition control then sends a high-voltage electrical current to the spark igniter which in turn ignites the main burner air/gas mixture.
14. Premix burner.
15. Spark Ignition Control. When energized, sends the electrical current to the spark igniter.
16. Temperature Probe: The water heater's control system monitors this probe to measure The heater's water temperature. The probe also houses the ECO (energy cut out) switch. This is a non adjustable high temperature limit switch. The ECO switch contacts are normally closed and will open on a temperature rise. See **High Temperature Limit Control (ECO)** (page 35).
17. Powered anode rods: The water heater's covered in this manual are equipped with 3 powered (non sacrificial) anode rods at the top. Protective current is fed by the control system to the titanium electrodes at the end of each anode rod. This current flows through the water to the conductive surfaces inside the storage tank which diminishes the corrosive effect of water when it comes in contact with steel.
18. Blocked Intake Air switch. Normally closed contacts that open on fall in pressure. This switch is used to insure intake (combustion) air to the water heater is not restricted. The control system monitors this switch and will disable heating operation if its contacts are open during a heating cycle.
19. Blocked Exhaust (vent) switch. Normally closed contacts that open on a rise in pressure. This switch is used to insure the Exhaust (vent) piping connected to the water heater is not restricted. The control system monitors this switch and will disable heating operation if its contacts are open during a heating cycle.
20. CPAM (Commercial powered anode module ).
21. Power supplier for CPAM.
22. 75VA transformer.
23. Side-mounted powered anodes.
24. Heater's internal recirculation pump.
25. Flow switch, vertically mounted, used for confirmation of water flowing through the secondary heat exchanger during the heater's running.
26. Flue temperature sensor.
27. 2" NPT Gas supply connection.
28. Water heater drain valve.
29. 2"NPT cold water inlet connection
30. 2" NPT hot water outlet connection.
31. 1" NPT building recirculation return connection.
32. 1/2" NPT condensate drain connection.
33. Cleanout access panel, covers water heater cleanout opening and ASME plate.

# INSTALLATION CONSIDERATIONS

## ROUGH-IN DIMENSIONS




Figure 4. Rough-In Dimensions

These designs comply with the current edition of the *American National Standard for Gas Fired Water Heaters, Volume III, ANSI Z21.10.3- CSA 4.3*. The 750 and 1000 models are Automatic Circulating Tank Water Heaters or Automatic Instantaneous Water Heaters.

Model	Series	NATURAL GAS	PROPANE GAS
750	100/101	2" NPT	2" NPT
1000	100/101	2" NPT	2" NPT

Gallons	*Natural Gas	Propane Gas
750	2" NPT	1 1/2" NPT
1000	2" NPT	1 1/2" NPT

Model	U.S. Gallons	Liters
	ASME	ASME
All	120	454

Model	*Manifold Pressure		Minimum Supply Pressure		Maximum Supply Pressure	
	Natural Gas	Propane Gas	Natural Gas	Propane Gas	Natural Gas	Propane Gas
750	0" W. C. (0 kPa)	0" W. C. (0 kPa)	3.5" W. C. (0.87 kPa)	8" W. C. (1.99 kPa)	14" W. C. (3.49 kPa)	14" W. C. (3.49 kPa)
1000	0" W. C. (0 kPa)	0" W. C. (0 kPa)	3.5" W. C. (0.87 kPa)	8" W. C. (1.99 kPa)	14" W. C. (3.49 kPa)	14" W. C. (3.49 kPa)

\* The manifold pressure is the factory setting and is not adjustable. A negative pressure will be seen with just the blower running without the Gas Control Valve open.

Model	Type of Gas	Input		Thermal Efficiency%	U. S. Gallons/hr & Liters/hr a Temperature Rise Indicated													
		Btu/hr	kW		°F	30°F	40°F	50°F	60°F	70°F	80°F	90°F	100°F	110°F	120°F	130°F	140°F	
750	Natural	750,000	220	97	°C	17°C	22°C	28°C	33°C	39°C	44°C	50°C	56°C	61°C	67°C	72°C	78°C	
	GPH				2940	2205	1764	1469	1260	1103	979	882	802	734	678	630		
1000	Natural	1,000,000	293	97	°C	17°C	22°C	28°C	33°C	39°C	44°C	50°C	56°C	61°C	67°C	72°C	78°C	
	LPH				11129	8347	6677	5561	4770	4175	3706	3339	3036	2778	2567	2385		

## LOCATING THE WATER HEATER

Carefully choose a location for the new water heater. The placement is a very important consideration for the safety of the occupants in the building and for the most economical use of the water heater.

### CAUTION

#### Property Damage Hazard

- All water heaters eventually leak.
- Do not install without adequate drainage.

Whether replacing an existing water heater or installing the water heater in a new location observe the following critical points:

1. The water heater must be located indoors.
2. The water heater must not be located in an area where it will be subject to freezing temperatures.
3. Locate the water heater so it is protected and not subject to physical damage by a moving vehicle.
4. Locate the water heater on a level surface.
5. Locate the water heater near a floor drain. The water heater should be located in an area where leakage of the tank or connections will not result in damage to the area adjacent to the water heater or to lower floors of the structure. When such locations cannot be avoided, it is recommended that a metal drain pan, adequately drained, be installed under the water heater.
6. Locate the water heater close to the point of major hot water usage.
7. Locate the water heater close to a 120 VAC power supply. See **Power Supply** (page 13) for requirements.
8. Locate the water heater where an adequate supply of fresh air for combustion and ventilation can be obtained. See **Air Requirements** (page 17).
9. Locate the water heater where the vent and intake air piping, when installed, will remain within the maximum equivalent lengths allowed. See **Venting Requirements** (page 21).
10. Do not locate the water heater where noise (such as the Combustion Blower) during normal operation will be objectionable in adjacent areas.

11. Do not locate the water heater where the subsequent installation of the vent (exhaust) or intake air terminations would be objectionable due to noise at the termination(s). This includes locations close to or across from windows and doors. See **Venting Installation** (page 20).

### WARNING

#### Fire or Explosion Hazard

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- Avoid all ignition sources if you smell gas.
- Do not expose water heater controls to excessive gas pressure.
- Use only the gas shown on the water heater rating label.
- Maintain required clearances to combustibles.
- Keep ignition sources away from faucets after extended periods of non-use.



Read instruction manual before installing, using or servicing water heater.



There is a risk in using fuel burning appliances such as gas water heaters in rooms, garages or other areas where gasoline, other flammable liquids or engine driven equipment or vehicles are stored, operated or repaired. Flammable vapors are heavy and travel along the floor and may be ignited by the water heater's igniter or Main Burner flames causing fire or explosion.

Flammable items, pressurized containers or any other potential fire hazardous articles must never be placed on or adjacent to the water heater.

#### CLEARANCE TO COMBUSTIBLE MATERIALS

The water heaters covered in this manual are approved for installation on combustible flooring. The clearance to combustible and non combustible construction materials is 0 cm (0 inches) on the back and sides of the water heater. These water heaters are also approved for installation in an alcove.

When the water heater is installed directly on carpeting, the water heater shall be installed on a metal or wood panel extending beyond the full width and depth of the water heater by at least 3 in (76.2 mm) in any direction or, if the water heater is installed in an alcove or closet, the entire floor shall be covered by the panel. The panel must be strong enough to carry the weight of the heater when full of water.

**Note:** Adequate clearance for servicing should be maintained on all installations. See **Service Clearance** (page 12).




Figure 5. Clearances

### SERVICE CLEARANCE

A service clearance of 61 cm (24 inches) should be maintained from serviceable parts such as the T&P valve, control system components, gas valve, clean out opening, drain valve, the vent connection (exhaust/condensate elbow) and the condensate drain. Leave as much room as possible above the water heater and near the exhaust elbow for this reason.

### INTAKE AIR AND VENT PIPE CLEARANCES

The minimum clearance from combustible materials for the vent (exhaust) and intake air piping shall be 0 cm (0 inches). Vent or intake air piping passing through a combustible wall or ceiling must be a continuous run (no joints).

### HARD WATER

Where hard water conditions exist, water softening or the threshold type of water treatment is recommended. This will protect the dishwashers, coffee urns, water heaters, water piping and other equipment. See **Sequence of Operation** (page 52) for sediment and lime scale removal procedures.

### CIRCULATION PUMPS

A circulating pump is used when a system requires a circulating loop or there is a storage tank used in conjunction with the water heater. The tank is provided with a 1" NPT recirculation loop return connection. See **Water Piping Diagrams** (page 65) for installation location of circulating pumps.

See **Circulation Pump Wiring Diagrams** (page 64) for electrical hookup information. Install in accordance with the current edition of the **National Electrical Code, NFPA 70** or the **Canadian Electrical Code, CSA C22.1**. Stainless steel circulating pumps are recommended for use with commercial water heaters.

See the circulating pump manufacturer's instructions for its operation, lubrication, and maintenance instructions.

### INSULATION BLANKETS

Insulation blankets are available to the general public for external use on gas water heaters but are not necessary with these products. The purpose of an insulation blanket is to reduce the standby heat loss encountered with storage tank heaters. The water heaters covered by this manual meet or exceed the **Energy Policy Act** standards with respect to insulation and standby heat loss requirements, making an insulation blanket unnecessary.

<b>⚠ WARNING</b>	
<b>Breathing Hazard - Carbon Monoxide Gas</b>	
	<ul style="list-style-type: none"> <li>• Do not obstruct water heater air intake with insulating blanket.</li> <li>• Gas and carbon monoxide detectors are available.</li> <li>• Install water heater in accordance with the instruction manual.</li> </ul>
<p>Breathing carbon monoxide can cause brain damage or death. Always read and understand instruction manual.</p>	

If you choose to apply an insulation blanket to this heater, you should follow these instructions. See **Features and Components** (page 8) for identification of components mentioned below. Failure to follow these instructions can restrict the air flow required for proper combustion, potentially resulting in fire, asphyxiation, serious personal injury or death.

- **DO NOT** apply insulation to the top of the water heater, as this will interfere with safe operation of the blower assembly.
- **DO NOT** cover the control system LCD on top of the water heater.
- **DO NOT** cover the Temperature-Pressure Relief Valve.
- **DO NOT** cover the instruction manual. Keep it on the side of the water heater or nearby for future reference.
- **DO** obtain new warning and instruction labels from the manufacturer for placement on the blanket directly over the existing labels.
- **DO** inspect the insulation blanket frequently to make certain it does not sag, thereby obstructing combustion air flow.

# INSTALLATION REQUIREMENTS

## SUPPLY GAS LINE REQUIREMENTS

Low-pressure building supply systems are defined as those systems that cannot under any circumstances exceed 14" W.C. (1/2 PSI Gauge). These systems do not require pressure regulation. Measurements should be taken to insure that gas pressures are stable and fall within the requirements stated on the water heater rating plate. Readings should be taken with all gas burning equipment off (static pressure) and with all gas burning equipment running at maximum rate (dynamic pressure). The gas supply pressure must be stable within 1.5" W.C. from static to dynamic pressure to provide good performance. Pressure drops that exceed 1.5" W.C. may cause rough starting, noisy combustion or nuisance outages. Increases or spikes in static pressure during off cycles may cause failure to ignite or in severe cases damage to appliance gas valves. If your low pressure system does NOT meet these requirements, the installer is responsible for the corrections.

High-pressure building supply systems use pressures that exceed 14" W.C. (1/2 PSI Gauge). These systems must use field supplied regulators to lower the gas pressure to less than 14" W.C. (1/2 PSI Gauge). Water heaters require gas regulators that are properly sized for the water heater input and deliver the rating plate specified pressures. Gas supply systems where pressure exceeds 5 PSI often require multiple regulators to achieve desired pressures. Systems in excess of 5 PSI building pressure should be designed by gas delivery professionals for best performance. Water heaters connected to gas supply systems that exceed 14" W.C. (1/2 PSI Gauge) at any time must be equipped with a gas supply regulator.

All models require a minimum gas supply pressure of 3.5" W.C. for natural gas and 8.0" W.C. for propane gas. The minimum supply pressure is measured while gas is flowing (dynamic pressure). The supply pressure should never fall below 3.5" W.C. for natural gas and 8.0" W.C. for propane gas. The supply pressure should be measured with all gas fired appliances connected to the common main firing at full capacity. If the supply pressure drops more than 1.5" W.C. as gas begins to flow to the water heater then the supply gas system including the gas line and/or the gas regulator may be restricted or undersized. See **Supply Gas Regulator** (page 13) and **Supply Gas Line Sizing** (page 31). The gas valve on all models has a maximum gas supply pressure limit of 14" W.C. The maximum supply pressure is measured while gas is not flowing (static pressure).

## SUPPLY GAS REGULATOR

The maximum allowable gas supply pressure for this water heater is 14.0" W. C. (3.49 kPa) for natural and propane gas. Install a positive lock-up gas pressure regulator in the gas supply line if inlet gas pressure can exceed these pressures at any time.

1. If a positive lock-up regulator is required follow these instructions:
2. Positive lock-up gas pressure regulators must be rated at or above the input Btu/hr rating of the water heater they supply.
3. Supply gas regulators shall have inlet and outlet connections not less than the minimum supply gas line size for the water heater they supply. See **Table 11** and **Table 12** (page 31).
4. Positive lock-up gas pressure regulator(s) should be installed no closer than 3 feet (1 meter) and no farther than 8 feet

(2.4 meters) from the water heater's inlet gas connection.

5. After installing the positive lock-up gas pressure regulator(s) an initial nominal supply pressure setting of 7.0" W.C. while the water heater is operating is recommended and will generally provide good water heater operation. Some additional adjustment maybe required later to maintain a steady gas supply pressure.

When installing multiple water heaters in the same gas supply system it is recommended that individual positive lock-up gas pressure regulators be installed at each unit.

## POWER SUPPLY

The water heaters covered in this manual require a 120 VAC, 1Ø (single phase), 60Hz, 15 amp power supply and must also be electrically grounded in accordance with local codes or, in the absence of local codes, with the **National Electrical Code, ANSI/NFPA 70** or the **Canadian Electrical Code, CSA C22.1**.

## DEDICATED POWER WIRING AND BREAKERS

Dedicated power supply wires, neutral wires, ground wiring and dedicated circuit breakers often prevent electrical line noise and are required when installing the water heater.

**Note:** This water heater should not be connected to an electrical supply with a Ground Fault Circuit Interrupter (GFCI) or Arc Fault Circuit Interrupter (AFCI) with Integral GFCI protection as defined in **NFPA 70, CSA C22.1** and **UL 943**.


## POWER FLUCTUATIONS AND ELECTRICAL NOISE

The water heater's control system requires a source of stable clean electricity for proper operation. Connecting the water heater to a branch circuit that is subject to fluctuations in voltage level or electrical line noise such as EMI (electro magnetic interference) or RFI (radio frequency interference) may cause erratic control system operation and malfunction.

A high quality power supply filter/suppressor must be installed if the above conditions exist. Call the technical support phone number listed on the back cover of this manual for more information.

**Note:** Malfunctions caused by the power supply and the costs to install power supply filters are not covered under the limited warranty.

## MIXING VALVES

	<p>Water temperature over 125°F (52°C) can cause severe burns instantly resulting in severe injury or death.</p> <p>Children, the elderly and the physically or mentally disabled are at highest risk for scald injury.</p> <p>Feel water before bathing or showering.</p> <p>Temperature limiting devices such as mixing valves must be installed when required by codes and to ensure safe temperatures at fixtures.</p>
--	--


Water heated to a temperature which will satisfy clothes washing, dish washing, and other sanitizing needs can scald and cause permanent injury upon contact. Short repeated heating cycles caused by small hot water uses can cause temperatures at the point of use to exceed the water heater's temperature setting by up to 20°F (11°C).

Some people are more likely to be permanently injured by hot water than others. These include the elderly, children, the infirm and the physically/mentally disabled. **Table 6** shows the approximate time-to-burn relationship for normal adult skin. If anyone using hot water provided by the water heater being installed fits into one of these groups or if there is a local code or state law requiring a certain water temperature at the point of use, then special precautions must be taken.

In addition to using the lowest possible temperature setting that satisfies the demand of the application, a mixing valve can be installed, for example, at the water heater or at the hot water taps to further reduce system water temperature. See **Figure 6**.

Check State and/or local codes for mixing valve requirements and installation practices.

Mixing valves are available at plumbing supply stores. Consult a Qualified Installer or Service Agency. Follow mixing valve manufacturer's instructions for installation of the valves.



**Figure 6. Mixing Valve**

The **National Sanitation Foundation** also recommends circulation of 180°F (82°C) water. The circulation should be just enough to provide 180°F (82°C) water at the point of take-off to the dish-washing machine.

Adjust flow by throttling a full port ball valve installed in the circulating line on the outlet side of the pump. Never throttle flow on the suction side of a pump. See the **Water Piping Diagrams** (page 65).

**Note:** To comply with **NSF Standard 5** installation requirements the bottom of the water heater must be sealed to the floor with a silicone based sealant or elevated 15 cm (6 inches) above the floor.

**CLOSED WATER SYSTEMS**

Water supply systems may, because of code requirements or such conditions as high line pressure, among others, have installed devices such as pressure reducing valves, check valves, and back flow preventers. Devices such as these cause the water system to be a closed system.

**THERMAL EXPANSION**

As water is heated, it expands (thermal expansion). In a closed system the volume of water will grow when it is heated. As the volume of water grows there will be a corresponding increase in water pressure due to thermal expansion. Thermal expansion can cause premature tank failure (leakage). This type of failure is not covered under the limited warranty. Thermal expansion can also cause intermittent Temperature-Pressure Relief Valve operation: water discharged from the valve due to excessive pressure build up. This condition is not covered under the limited warranty. The Temperature-Pressure Relief Valve is not intended for the constant relief of thermal expansion.

A properly sized and pressurized thermal expansion tank must be installed on all closed systems to control the harmful effects of thermal expansion. Contact a local plumbing service agency to have a thermal expansion tank installed.

See **Water Line Connections** (page 58) and the **Water Piping Diagrams** (page 65).


Table 6. Burn Time at Various Temperatures		
Water Temperature °F (°C)	Time for 1st Degree Burn (Less Severe Burns)	Time for Permanent Burns 2nd & 3rd Degree (Most Severe Burns)
110 (43)	(normal shower temp.)	
116 (47)	(pain threshold)	
116 (47)	35 minutes	45 minutes
122 (50)	1 minute	5 minutes
131 (55)	5 seconds	25 seconds
140 (60)	2 seconds	5 seconds
149 (65)	1 second	2 seconds
154 (68)	instantaneous	1 second

(U.S. Government Memorandum, C.P.S.C., Peter L. Armstrong, Sept. 15, 1978)

**DISH-WASHING MACHINES**

All dish-washing machines meeting the **National Sanitation Foundation** requirements are designed to operate with water flow pressures between 15 and 25 pounds per square inch (103 kPa and 173 kPa). Flow pressures above 25 pounds per square inch (173 kPa), or below 15 pounds per square inch (103 kPa), will result in improperly sanitized dishes. Where pressures are high, a water pressure reducing or flow regulating control valve should be used in the 180°F (82°C) line to the dish-washing machine and should be adjusted to deliver water pressure between these limits.

## TEMPERATURE-PRESSURE RELIEF VALVE

	<b>⚠ WARNING</b>
	<b>Explosion Hazard</b>
	<ul style="list-style-type: none"><li>• Temperature-Pressure Relief Valve must comply with ANSI Z21.22- CSA 4.4 and ASME code.</li><li>• Properly sized temperature-pressure relief valve must be installed in opening provided.</li><li>• Can result in overheating and excessive tank pressure.</li><li>• Can cause serious injury or death.</li></ul>

This water heater is provided with a properly rated/sized and certified combination Temperature-Pressure Relief Valve (T&P valve) by the manufacturer. The valve is certified by a nationally recognized testing laboratory that maintains periodic inspection of production of listed equipment of materials as meeting the requirements for *Relief Valves for Hot Water Supply Systems, ANSI Z21.22 • CSA 4.4*, and the code requirements of *ASME*.

If replaced, the new T&P valve must meet the requirements of local codes, but not less than a combination Temperature-Pressure Relief Valve rated/sized and certified as indicated in the above paragraph. The new valve must be marked with a maximum set pressure not to exceed the marked hydrostatic working pressure of the water heater (150 psi = 1,035 kPa) and a discharge capacity not less than the water heater Btu/hr or kW input rate as shown on the water heater's model rating label.

**Note:** In addition to the factory installed Temperature-Pressure Relief Valve on the water heater, each remote storage tank that may be installed and piped to a water heating appliance must also have its own properly sized, rated and approved Temperature-Pressure Relief Valve installed. Call the toll free technical support phone number listed on the back cover of this manual for technical assistance in sizing a Temperature-Pressure Relief Valve for remote storage tanks.

For safe operation of the water heater, the Temperature-Pressure Relief Valve must not be removed from its designated opening nor plugged. The Temperature-Pressure Relief Valve must be installed directly into the fitting of the water heater designed for the relief valve. Install discharge piping so that any discharge will exit the pipe within 30 cm (12 inches) above an adequate floor drain, or external to the building. In cold climates it is recommended that it be terminated at an adequate drain inside the building. Be certain that no contact is made with any live electrical part. The discharge opening must not be blocked or reduced in size under any circumstances. Excessive length, over 9 m (30 feet), or use of more than four elbows can cause restriction and reduce the discharge capacity of the valve.


No valve or other obstruction is to be placed between the Temperature-Pressure Relief Valve and the tank. Do not connect discharge piping directly to the drain unless a 30 cm (12 inches) air gap is provided. To prevent bodily injury, hazard to life, or property damage, the relief valve must be allowed to discharge water in adequate quantities should circumstances demand. If the

discharge pipe is not connected to a drain or other suitable means, the water flow may cause property damage.

<b>CAUTION</b>
<b>Water Damage Hazard</b>
<ul style="list-style-type: none"><li>• Temperature-Pressure Relief Valve discharge pipe must terminate at adequate drain.</li></ul>

### T&P Valve Discharge Pipe Requirements:

- Shall not be smaller in size than the outlet pipe size of the valve, or have any reducing couplings or other restrictions.
- Shall not be plugged or blocked.
- Shall not be exposed to freezing temperatures.
- Shall be of material listed for hot water distribution.
- Shall be installed so as to allow complete drainage of both the Temperature-Pressure Relief Valve and the discharge pipe.
- Must terminate a maximum of 15 cm (6 inches) above a floor drain or external to the building. In cold climates, it is recommended that the discharge pipe be terminated at an adequate drain inside the building.
- Shall not have any valve or other obstruction between the relief valve and the drain.

<b>⚠ DANGER</b>	<ul style="list-style-type: none"><li>• Burn hazard.</li><li>• Hot water discharge.</li><li>• Keep clear of Temperature-Pressure Relief Valve discharge outlet.</li></ul>
	

The Temperature-Pressure Relief Valve must be manually operated at least twice a year. Caution should be taken to ensure that (1) no one is in front of or around the outlet of the Temperature-Pressure Relief Valve discharge line, and (2) the water manually discharged will not cause any bodily injury or property damage because the water may be extremely hot. If after manually operating the valve, it fails to completely reset and continues to release water, immediately close the cold water inlet to the water heater, follow the draining instructions in this manual, and replace the Temperature-Pressure Relief Valve with a properly rated/sized new one.

**Note:** The purpose of a Temperature-Pressure Relief Valve is to prevent excessive temperatures and pressures in the storage tank. The T&P valve is not intended for the constant relief of thermal expansion. A properly sized thermal expansion tank must be installed on all closed systems to control thermal expansion. See *Closed Water Systems* (page 14) and *Temperature-Pressure Relief Valve* (page 15).

If you do not understand these instructions or have any questions regarding the Temperature-Pressure Relief Valve call the toll free number listed on the back cover of this manual for technical assistance.

## CONDENSATE DRAIN

The water heaters covered in this manual are condensing appliances and require a building drain to be located in close proximity to allow the condensate to drain safely.

Condensate drains from the water heater near the bottom below the drain valve. The field-installed condensate drain line must not be elevated above the condensate drain connection. See **Figure 7**. If the condensate does not drain properly, it will build up in the exhaust outlet. This will restrict the flow of flue gases and cause the Blocked Exhaust pressure switch to open its contacts. The control system monitors all pressure switches, if the Blocked Exhaust Switch contacts are open the control system will lock out and disable heating operation. The "Blocked Exhaust" fault message will be displayed on the control system's LCD. See **Fault and Alert Conditions** (page 55).

The water heater has a built-in condensate trap. Do not install an additional trap in the condensate drain piping. See **Figure 7**.

If the "Blocked Exhaust" Fault message is ever displayed on the control system LCD, check the condensate drain first and ensure that it is not blocked.




Figure 7. Condensate Trap

## CONDENSATE PH LEVEL

The condensate drains from the water heater's covered in this manual have pH levels between 4.3 and 5.0. Install a commercially available neutralizing kit if required by local codes.

**Note:** Lower pH levels are acidic. Do not connect a metal drain line, such as copper, to the water heater for this reason. See **Condensate Drain Installation** (page 30).

## COMBUSTIBLE MATERIAL STORAGE

### ⚠ WARNING

#### Fire or Explosion Hazard

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- Avoid all ignition sources if you smell gas.
- Do not expose water heater controls to excessive gas pressure.
- Use only the gas shown on the water heater rating label.
- Maintain required clearances to combustibles.
- Keep ignition sources away from faucets after extended periods of non-use.



Read instruction manual before installing, using or servicing water heater.



Keep appliance area clear and free of combustible materials, gasoline and other flammable vapors and liquids.

## CONTAMINATED AIR

### ⚠ WARNING

#### Breathing Hazard - Carbon Monoxide Gas



- Install water heater in accordance with the Instruction Manual and NFPA 54 or CAN/CSA-B149.1.
- To avoid injury, combustion and ventilation air must be taken from outdoors.
- Do not place chemical vapor emitting products near water heater.

Breathing carbon monoxide can cause brain damage or death. Always read and understand instruction manual.

Corrosion of the flue ways and vent system may occur if air for combustion contains certain chemical vapors. Such corrosion may result in failure and risk of asphyxiation.


Combustion air that is contaminated can greatly diminish the life span of the water heater and water heater components such as hot surface igniters and burners. Propellants of aerosol sprays, beauty shop supplies, water softener chemicals and chemicals used in dry cleaning processes that are present in the combustion, ventilation or ambient air can cause such damage.

Do not store products of this sort near the water heater. Air which is brought in contact with the water heater should not contain any of these chemicals. If necessary, uncontaminated air should be obtained from remote or outdoor sources. The limited warranty is voided when failure of water heater is due to a corrosive atmosphere. (See the limited warranty for complete terms and conditions).

If the water heater will be used in beauty shops, barber shops, cleaning establishments, or self-service laundries with dry cleaning equipment, it is imperative that the water heater(s) be installed in a Direct Vent configuration so that all air for combustion is derived directly from the outdoor atmosphere through a sealed intake air pipe. See **Venting Installation** (page 20).



## AIR REQUIREMENTS

<b>⚠ WARNING</b>	
<b>Breathing Hazard - Carbon Monoxide Gas</b>	
	<ul style="list-style-type: none"><li>• Install water heater in accordance with the Instruction Manual and NFPA 54 or CAN/CSA-B149.1.</li><li>• To avoid injury, combustion and ventilation air must be taken from outdoors.</li><li>• Do not place chemical vapor emitting products near water heater.</li></ul>
Breathing carbon monoxide can cause brain damage or death. Always read and understand instruction manual.	

For safe operation an adequate supply of fresh uncontaminated air for combustion and ventilation must be provided.

An insufficient supply of air can cause recirculation of combustion products resulting in contamination that may be hazardous to life. Such a condition often will result in a yellow, luminous burner flame, causing sooting of the combustion chamber, burners and flue tubes and creates a risk of asphyxiation.

Do not install the water heater in a confined space unless an adequate supply of air for combustion and ventilation is brought in to that space using the methods described in the Confined Space section that follows.

Never obstruct the flow of ventilation air. If you have any doubts or questions at all, call your gas supplier. Failure to provide the proper amount of combustion air can result in a fire or explosion and cause property damage, serious bodily injury or death.

### UNCONFINED SPACE

An Unconfined Space is one whose volume IS NOT LESS THAN 50 cubic feet per 1,000 Btu/hr (4.8 cubic meters per kW) of the total input rating of all appliances installed in the space. Rooms communicating directly with the space, in which the appliances are installed, through openings not furnished with doors, are considered a part of the unconfined space.

Makeup air requirements for the operation of exhaust fans, kitchen ventilation systems, clothes dryers and fireplaces shall also be considered in determining the adequacy of a space to provide combustion, ventilation and dilution air.

### UNUSUALLY TIGHT CONSTRUCTION

In unconfined spaces in buildings, infiltration may be adequate to provide air for combustion, ventilation and dilution of flue gases. However, in buildings of unusually tight construction (for example, weather stripping, heavily insulated, caulked, vapor barrier, etc.) additional air must be provided using the methods described in the Confined Space section that follows.

## CONFINED SPACE

A Confined Space is one whose volume IS LESS THAN 50 feet<sup>3</sup> per 1,000 Btu/hr (4.8 cm per kW) of the total input rating of all appliances installed in the space.

Openings must be installed to provide fresh air for combustion, ventilation and dilution in confined spaces. The required size for the openings is dependent on the method used to provide fresh air to the confined space AND the total Btu/hr input rating of all appliances installed in the space.

### DIRECT VENT APPLIANCES

Appliances installed in a Direct Vent configuration that derive all air for combustion from the outdoor atmosphere through sealed intake air piping are not factored in the total appliance input Btu/hr calculations used to determine the size of openings providing fresh air into confined spaces.

### EXHAUST FANS

Where exhaust fans are installed, additional air shall be provided to replace the exhausted air. When an exhaust fan is installed in the same space with a water heater, sufficient openings to provide fresh air must be provided that accommodate the requirements for all appliances in the room and the exhaust fan. Undersized openings will cause air to be drawn into the room through the water heater's vent system causing poor combustion. Sooting, serious damage to the water heater and the risk of fire or explosion may result. It can also create a risk of asphyxiation.

### LOUVERS AND GRILLES

The free areas of the fresh air openings in the instructions that follow do not take in to account the presence of louvers, grilles or screens in the openings.

The required size of openings for combustion, ventilation and dilution air shall be based on the "net free area" of each opening. Where the free area through a design of louver or grille or screen is known, it shall be used in calculating the size of the opening required to provide the free area specified. Where the louver and grille design and free area are not known, it shall be assumed that wood louvers will have 25% free area and metal louvers and grilles will have 75% free area. Non motorized louvers and grilles shall be fixed in the open position.


### FRESH AIR OPENINGS FOR CONFINED SPACES

The following instructions shall be used to calculate the size, number and placement of openings providing fresh air for combustion, ventilation and dilution in confined spaces. The illustrations shown in this section of the manual are a reference for the openings that provide fresh air into confined spaces only.

**DO NOT** refer to these illustrations for the purpose of vent installation. See *Venting Installation* (page 20) for complete venting installation instructions.

### OUTDOOR AIR THROUGH TWO OPENINGS

The confined space shall be provided with two permanent openings, one commencing within 300 mm (12 inches) of the top and one commencing within 300 mm (12 inches) of the bottom of the enclosure. The openings shall communicate directly with the outdoors. See *Figure 8*.




**Figure 8. Outdoor Air Through Two Openings**

Each opening shall have a minimum free area of 1 square inch per 4,000 Btu/hr (550 mm<sup>2</sup> per kW) of the aggregate input rating of all appliances installed in the enclosure. Each opening shall not be less than 645 cm<sup>2</sup> (100 square inches).

### OUTDOOR AIR THROUGH ONE OPENING

Alternatively a single permanent opening, commencing within 300 mm (12 inches) of the top of the enclosure, shall be provided. See *Figure 9*.



**Figure 9. Outdoor Air Through One Opening**

The water heater shall have clearances of at least 25 mm (1 inch) from the sides and back and 150 mm (6 inches) from the front of the water heater. The opening shall directly communicate with the outdoors or shall communicate through a vertical or horizontal duct to the outdoors or spaces that freely communicate with the outdoors and shall have a minimum free area of the following:


1. One square inch per 3000 Btu/hr (700 mm<sup>2</sup> per kW) of the total input rating of all appliances located in the enclosure,

and

2. Not less than the sum of the areas of all vent connectors in the space.

### OUTDOOR AIR THROUGH TWO HORIZONTAL DUCTS

The confined space shall be provided with two permanent horizontal ducts, one commencing within 300 mm (12 inches) of the top and one commencing within 300 mm (12 inches) of the bottom of the enclosure. The horizontal ducts shall communicate directly with the outdoors. See *Figure 10*.



**Figure 10. Two Horizontal Ducts**


Each duct opening shall have a minimum free area of 1100 mm<sup>2</sup>/kW (1 square inch per 2,000 Btu/hr) of the aggregate input rating of all appliances installed in the enclosure.

When ducts are used, they shall be of the same cross sectional area as the free area of the openings to which they connect. The minimum dimension of rectangular air ducts shall be not less than 76 mm (3 inches).

### OUTDOOR AIR THROUGH TWO VERTICAL DUCTS

The illustrations shown in this section of the manual are a reference for the openings that provide fresh air into confined spaces only.

**DO NOT** refer to these illustrations for the purpose of vent installation. See *Venting Installation* (page 20) for complete venting installation instructions.



**Figure 11. Two Vertical Ducts**


The confined space shall be provided with two permanent vertical ducts, one commencing within 300 mm (12 inches) of the top and one commencing within 300 mm (12 inches) of the bottom of the enclosure. The vertical ducts shall communicate directly with the outdoors. See *Figure 11*.

Each duct opening shall have a minimum free area of 550 mm<sup>2</sup> per kW (1 square inch per 4,000 Btu/hr) of the aggregate input rating of all appliances installed in the enclosure.

When ducts are used, they shall be of the same cross sectional area as the free area of the openings to which they connect. The minimum dimension of rectangular air ducts shall be not less than 76 cm (3 inches).

#### **AIR FROM OTHER INDOOR SPACES**

The confined space shall be provided with two permanent openings, one commencing within 300 mm (12 inches) of the top and one commencing within 300 mm (12 inches) of the bottom of the enclosure. See *Figure 12*.



**Figure 12. Two Permanent Openings**


Each opening shall communicate directly with an additional room(s) of sufficient volume so that the combined volume of all spaces meets the criteria for an unconfined space.

Each opening shall have a minimum free area of 1100 mm<sup>2</sup>/kW (1 square inch per 1,000 Btu/hr) of the aggregate input rating of all appliances installed in the enclosure. Each opening shall not be less than 645 cm<sup>2</sup> (100 square inches).

# VENTING INSTALLATION

## WARNING

### Breathing Hazard - Carbon Monoxide Gas



- Install vent system in accordance with codes.
- Do not operate water heater if exposed to flooding or water damage
- Special consideration must be taken with installations above 10,000 feet (3,048 m) refer to high altitude section of this manual.
- Do not operate if soot buildup.
- Do not obstruct water heater air intake with insulating jacket or blanket.
- Do not place chemical vapor emitting products near water heater.
- Gas and carbon monoxide detectors are available.
- Never operate the heater unless it is vented to the outdoors and has adequate air supply to avoid risks of improper operation, fire, explosion or asphyxiation.
- Analyze the entire vent system to make sure that condensate will not become trapped in a section of vent pipe and therefore reduce the open cross sectional area of the vent.

Breathing carbon monoxide can cause brain damage or death. Always read and understand the instruction manual.

Never operate the water heater unless it is vented to outdoors. The instructions in this section of the manual must be followed to avoid choked combustion or recirculation of flue gases. Such conditions cause sooting of the combustion chamber, burners and flue tubes and creates a risk of asphyxiation.

### GENERAL VENTING INFORMATION

The water heaters covered in this manual are Category IV appliances and may be installed in either a Power Vent or Direct Vent configuration.

### APPROVED MATERIALS

Approved vent and intake air pipe materials that may be used in the United States:

PVC pipe materials:

- DWV ASTM-D2665 or CSA B181.2
- Schedule 40, 80, 120 ASTM-D1785 or CSA B137.3
- SDR Series ASTM-2241 or CSA B137.3

CPVC pipe materials:

- CPVC 41 ASTM-D2846 or CSA B137.6
- Schedule 40, 80 ASTM-F441 or CSA B137.6
- SDR Series ASTM-F442

Polypropylene. See *Polypropylene Installations* (page 26).

- M & G Duravent PolyPro vent system
- Centrotherm InnoFlue vent system

AL29-4C Stainless Steel. See *AL29-4C® Vent Installations* (page 26).

- HeatFab Saf-T Vent
- Duravent FasNSeal

Approved vent pipe materials that must be used in Canada:

- ULC S636 PVC / CPVC
- ULC S636 Polypropylene. See *Polypropylene Installations* (page 26).
- AL29-4C Stainless Steel. See *AL29-4C® Vent Installations* (page 26)

Approved intake air pipe materials that must be used in Canada:

PVC pipe materials:

- DWV ASTM-D2665 or CSA B181.2
- Schedule 40, 80, 120 ASTM-D1785 or CSA B137.3
- SDR Series ASTM-D2241 or CSA B137.3

CPVC pipe materials:

- CPVC 41 ASTM-D2846 or CSA B137.6
- Schedule 40, 80 ASTM-F441 or CSA B137.6
- SDR Series ASTM-F442

Polypropylene. See *Polypropylene Installations* (page 26).

- M & G Duravent PolyPro vent system
- Centrotherm InnoFlue vent system

AL29-4C Stainless Steel. See *AL29-4C® Vent Installations* (page 26)

- HeatFab Saf-T Vent
- Duravent FasNSeal

Where applicable, the installation of the venting system should be done in accordance with the venting system manufacturer's instructions.

**Note:** The use of cellular core PVC (ASTM F891), cellular core CPVC, or Radel® (polyphenolsulfone) in non-metallic venting systems is prohibited. Covering non-metallic vent pipe and fittings with thermal insulation is prohibited.

### CATEGORY IV APPLIANCE

Category IV appliances operate with a positive vent (exhaust) static pressure and with vent gas temperatures low enough to produce condensate in the vent piping.

### POWER VENT CONFIGURATION

Power Vent configurations derive all combustion air from the room where they are installed and discharge all flue gases to the outdoor atmosphere through a sealed vent (exhaust) pipe. Power vent configurations have one vent pipe connected to the water heater which can be terminated in a vertical or horizontal arrangement. See *Venting Arrangements* (page 27).

### DIRECT VENT CONFIGURATION

Direct Vent configurations derive all combustion air directly from the outdoor atmosphere through a sealed intake air pipe and discharge all flue gases to the outdoor atmosphere through a sealed vent (exhaust) pipe. Direct Vent configurations have two pipes connected to the water heater, one vent pipe and one intake air pipe. Direct Vent configurations can be terminated in one of several different arrangements. See *Venting Arrangements* (page 27).

### GENERAL VENTING INSTRUCTIONS

These instructions must be followed on all installations.

1. DO NOT install the water heater in a Power Vent configuration unless there is adequate supply of fresh air. See *Air Requirements* (page 17). If the installation space does not provide an adequate supply of fresh air the water heater must be installed in a Direct Vent configuration.

2. If the water heater is to be installed in a beauty shop, barber shop, cleaning establishment, a laundry with dry cleaning equipment or any space with contaminated air it is imperative that the water heater(s) be installed in a Direct Vent configuration so that all air for combustion is derived from the outdoor atmosphere.
3. The vent and intake air piping must terminate outdoors.
4. The minimum clearance from combustible materials for the vent (exhaust) and intake air piping shall be 0 cm (0 inches). Vent piping passing through a combustible wall or ceiling must be a continuous run (no joints).
5. The water heater must be protected from freezing down-drafts during shutdown periods.
6. The vent (exhaust) pipe must not be combined or connected to any other appliance's vent system or chimney.
7. The intake air pipe must not be combined or connected to any other appliance's intake air piping.
8. Locate the water heater where the vent (exhaust) and intake air piping will remain within the maximum equivalent lengths allowed. See **Venting Requirements** (page 21).
9. Do not install the vent or intake air piping in a manner that will allow water to be trapped in the piping.
10. The vent (exhaust) piping must be pitched a minimum of a 2 cm/m (1/4 inch per foot) back to the water heater (to allow drainage of condensate).
11. Do not anchor the vent or intake air pipe directly to framed walls, floors or ceilings unless rubber isolation pipe hangers are used to prevent vibration noise from being transmitted.
12. Use only approved vent/intake air pipe sizes and materials. See **Venting Requirements** (page 21).
13. Use only factory supplied vent and intake air terminations. See **Venting Requirements** (page 21).
14. Do not locate the vent (exhaust) or intake air terminations where they would be objectionable due to noise at the termination(s). This includes locations close to or across from windows and doors.
15. Direct venting into dead air spaces such as alleys, atriums, and inside corners can cause recirculation of flue gases. Recirculation of flue gases will cause sooting, premature failure of the heat exchanger and icing of the combustion air intake during severe cold weather. To prevent the recirculation of flue gases, maintain as much distance as possible between the intake air and vent terminations.
16. Do not locate the vent termination over public walkways or a public area where condensate or vapor can cause a nuisance or ice hazard.
17. Ensure the screens in the factory supplied terminations are securely installed to prevent blockage in the vent system.
18. Stress levels in pipe/fittings can be significantly increased by improper installation. If rigid pipe clamps are used to hold the pipe in place, or if the pipe cannot move freely through a wall penetration, the pipe may be stressed, or high thermal stresses may be formed when the pipe heats up and

expands. Install accordingly to minimize such stresses.

19. Carefully read the **Venting Requirements** (page 21) and then proceed to the **Venting Installation Sequence** (page 22).

## VENTING REQUIREMENTS

---

### FIELD SUPPLIED FITTINGS

Field supplied fittings should be equivalent to the piping material being installed. Field installed/supplied fittings will add equivalent feet to the vent or intake air piping as indicated below. All field supplied/installed fittings and piping must be factored into the equivalent feet calculations.

- 90° elbows (short or long radius) are equivalent to 152 cm (5 linear feet) of pipe.
- 45° elbows (short or long radius) are equivalent to 76 cm (2.5 linear feet) of pipe.

**Note:** See **Table 9** and **Table 10** for equivalent linear pipe length of AL29-4C® 45° and 90° elbows.

### PIPING ATTACHED TO THE AIR INTAKE FITTING

Any piping added to the air intake fitting on the heater **MUST** be glued or attached with screws.

### PRIMER AND CEMENT

Tetrahydrofuran (THF) primer should be used to prepare the surfaces of pipe and fittings for solvent welding. If CPVC pipe and fittings are used, then the proper cement must be used for all joints, including joining the pipe to the factory provided terminations (PVC material). PVC Materials should use ASTM D-2564 Grade Cement; CPVC Materials should use ASTM F-493 Grade Cement.

### PIPE SIZE REQUIREMENTS

The water heaters covered in this manual are certified for the use six-inch pipe for the vent (exhaust) and intake air piping.

### Maximum Equivalent Lengths

The water heaters covered in this manual are certified to a maximum length of 6-inch pipe for the exhaust venting arrangement of 30,4 m (100 equivalent feet). The certified maximum length of 6-inch pipe for intake air piping is also 30,4 m (100 equivalent feet). For example, on Direct Vent installations, both pipes can be up to 30,4 m (100 equivalent feet).

### Intake Air and Vent Pipe Clearances

The minimum clearance from combustible materials for the vent (exhaust) and intake air piping shall be 0 cm (0 inches). Vent or intake air piping passing through a combustible wall or ceiling must be a continuous run (no joints).

### Minimum Equivalent Lengths

The water heaters covered in this manual are certified to a minimum length of six-inch pipe for the vent (exhaust) of 4,6 m (15 feet). There is no minimum equivalent feet requirement for the intake air pipe.

### Maximum Equivalent Lengths

The water heaters covered in this manual are certified to a maximum length of six-inch pipe for the exhaust venting arrangement of equivalent 30, 4 m (100 feet). The certified maximum length of six-inch pipe for intake air piping is also 30,

4 m (100 equivalent feet). In other words, on direct vent installations, both pipes can be up to 30, 4 m (100 equivalent).

### Maximum Number Of Elbows

The vent pipe may have a maximum of six 90° elbows installed. The intake air pipe may have a maximum of six 90° elbows installed. For example: in a Direct Vent configuration each pipe can have up to six 90° elbows installed. Two 45° elbows equal one 90° elbow. Each 90° elbow is equivalent to 1,5 m (5 feet) of linear pipe, 45° elbows are equivalent to 0,75 m (2.5 feet) of linear pipe.

**Note:** See **Table 9** and **Table 10** for equivalent linear pipe length of AL29-4C® 45° and 90° elbows.

### FACTORY SUPPLIED FITTINGS

The water heater ships with one vent kit box containing one six-inch coupling with screen for flue gas terminal, one six-inch 90-degree elbow with screen for air intake terminal, and two 45 degree venting elbows. Factory-supplied vent and intake air terminations must be used. Factory-supplied terminations and installed fittings (exhaust elbow and intake air connection) add zero equivalent feet to the vent and intake air piping.

### VENTING INSTALLATION SEQUENCE

1. Read the **General Venting Instructions** (page 20) and **Venting Requirements** (page 21) before proceeding. These instructions and requirements must be followed on all installations.
2. Determine whether the water heater will be installed in a Power Vent or Direct Vent configuration and which vent system arrangement will be used for the installation. See the various venting arrangements illustrated in **Venting Arrangements** (page 27).
3. Proceed to the applicable installation instructions that follow; **Power Vent Installation** (page 22) or **Direct Vent Installation** (page 22).

### POWER VENT INSTALLATION

1. Read the **General Venting Instructions** (page 20) and **Venting Requirements** (page 21) before proceeding. These instructions and requirements must be followed in addition to the instructions below that are specific for Power Vent configurations.
2. Determine which Power Vent arrangement will be used for the installation; vertical or horizontal termination. See **Venting Arrangements** (page 27).
3. Plan the layout of the vent piping backwards from the termination point outdoors to the water heater. Layout the vent piping to use a minimum of pipe and elbows.
4. Install the termination first.

If the vent piping will terminate vertically, through a roof. See **Vertical Termination Installation** (page 23).

If the vent piping will terminate horizontally, through a sidewall. See **Sidewall Termination Installation** (page 25).




Figure 13. Vent (Exhaust) Connection

5. When installation of the termination is complete install necessary piping and fittings to route the vent piping back to the water heater.
6. The vent pipe must be supported properly to avoid bending or failure. The water heater manufacturer recommends that the vent pipe be supported every 152 cm (5 feet) of vertical run and every 91 cm (3 feet) of horizontal run.
7. Do not install the vent piping in a manner that will allow water to be trapped in the piping.
8. All vent (exhaust) pipes must be pitched a minimum of a 2 cm/m (1/4 inch per foot) back to the water heater (to allow drainage of condensate).

### DIRECT VENT INSTALLATION

1. Read the **General Venting Instructions** (page 20) and **Venting Requirements** (page 21) before proceeding. These instructions and requirements must be followed in addition to the instructions below that are specific for Direct Vent configurations.
2. Determine which Direct Vent arrangement will be used for the installation.
3. Plan the layout of the vent and intake air piping backwards from the termination point outdoors to the water heater. Layout the vent and intake air piping to use a minimum of pipe and elbows.


**Note:** Any piping added to the air-intake fitting on the heater **MUST** be glued or attached with screws.

4. Install the terminations first.
5. When installation of the termination(s) is complete, install necessary piping and fittings to route the intake air and vent
6. The intake air and vent piping must be supported properly to avoid bending or failure. The water heater manufacturer recommends that the vent and intake air piping be supported every 152 cm (5 feet) of vertical run and every 91 cm (3 feet) of horizontal run.
7. Do not install the vent or intake air piping in a manner that will allow water to be trapped in the piping.
8. A field supplied condensate Tee fitting and drain hose must be installed in the intake air piping near the water heater in colder climates with heavy snow accumulations and in areas that regularly experience high humidity. The drain hose must be routed to an adequate floor drain separate from any other

condensate drains. See **Figure 14** (page 23).

**Note:** Snow being pulled into the intake air piping and then melting can lead to excessive amounts of water accumulation and damage water heater components. Warm, humid outdoor air can lead to excessive condensation inside the intake air piping and may also damage water heater components.

9. All vent (exhaust) pipes must be pitched a minimum of a 2 cm/m (1/4 inch per foot) back to the water heater (to allow drainage of condensate).
10. Use a torque wrench to tighten the vent pipe clamps to 24-34 IN/LBS.




**Figure 14. Intake Air Condensate Tee Installation**

11. Ensure the Intake Air Screen on the Intake Air Connection is removed before connecting the intake air pipe to the water heater. See **Figure 15**.

<b>⚠ WARNING</b>	
<b>Breathing Hazard - Carbon Monoxide Gas</b>	
	<ul style="list-style-type: none"> <li>• Do not obstruct water heater air intake.</li> <li>• Gas and carbon monoxide detectors are available.</li> <li>• Install water heater in accordance with the instruction manual.</li> </ul>
<p>Breathing carbon monoxide can cause brain damage or death. Always read and understand instruction manual.</p>	

**Note:** Do not leave the screen inside the Intake Air connection in Direct Vent installations. Once the intake air pipe is installed the screen will be hidden from view and may become clogged with debris over time. This will cause improper combustion.



**Figure 15. Intake-Air Connection Detail**

### DIRECT VENT AIR INTAKE MOISTURE PROTECTION

The air intake piping in a direct vent system will normally not have any moisture accumulation in it. However, in certain cases, moisture may build up and needs to be drained. Typical situations include, but are not limited to:

- Cold outdoor temperature, particularly if the air inlet is short
- High outdoor humidity
- Heater being used mostly for space heating
- Air inlet pipe has vertical rise near the heater

Installations with any of these conditions are required to provide a moisture drain with a trap that flows to a waste drain. See **Figure 14** (page 23) and **Venting Arrangements** (page 27). A horizontal section of the air inlet pipe, near the heater should include a hose barb fitting to drain the water. The drain tubing in any installation should have a loop trap and flow to an appropriate waste drain. The air intake drain line must be entirely separate from the exhaust vent outlet condensate line.

### VERTICAL TERMINATION INSTALLATION

1. Determine the location for the termination(s).
2. If installing only the vent (exhaust) piping in a Power Vent configuration vertically through the roof, ensure that all exterior vertical clearance requirements, shown in **Figure 16** and **Figure 17** (page 24), are being maintained. These clearances and those cited by local and national codes must be maintained.

**Note:** On flat roof installations the vent termination must be a minimum of 60 cm (24 inches) above any parapet, vertical wall, or structure within 3 m (10 feet) horizontally. See **Figure 17** (page 24).


3. If installing both intake air and vent piping in a Direct Vent configuration vertically through the roof; ensure that all exterior vertical clearance requirements shown in **Figure 17** and **Figure 18** (page 24) are being maintained. These clearances and those cited by local and national codes must be maintained.

**Note:** On flat roof installations the intake air and the vent terminations must be a minimum of 60 cm (24 inches) above any parapet, vertical wall or structure within 3 m (10 feet) horizontally. See **Figure 17** (page 24).

4. If installing only vent piping in a Power Vent configuration vertically through the roof, the following instructions must be followed:

- The vent termination must be oriented facing upward as shown in **Figure 17** (page 24).

- The bottom edge of the vent termination must be a minimum of 30 cm (12 inches), 45 cm (18 inches) in Canada, above the average or expected snow level as shown in **Figure 16**.
5. If installing both intake air and vent piping in a Direct Vent configuration vertically through the roof the following instructions must be followed:
    - The intake air and vent pipes must penetrate the same side of the roof as shown in **Figure 18** (page 24).
    - The intake air and vent terminations must be oriented as shown in **Figure 18**.
    - The intake air and vent terminations must have a minimum separation of 60 cm (24 inches) measured on center line as shown in **Figure 18**. In colder climates this separation should be increased to at least 122 cm (48 inches).
    - The bottom edge of the intake air and vent terminations must be a minimum of 30 cm (12 inches), 45 cm (18 inches) in Canada, above the average or expected snow level as shown in **Figure 16** and **Figure 18**.




**Figure 16. Vertical Termination(s) - Intake Air and/or Vent (Exhaust)**

6. When the intake air and/or vent piping from multiple water heaters will terminate in the same location the vent terminations can be grouped together in close proximity 0 cm (0 inches)/touching. Intake air terminations can also be grouped together in close proximity 0 cm (0 inches)/touching. The distance between the closest vent and intake air terminations must be a minimum of 60 cm (24 inches) as shown in **Figure 18**. In colder climates this separation should be increased to at least 122 cm (48 inches).
7. Cut an 18 cm (7 inch) diameter hole for six-inch pipe where the pipe(s) will pass through the roof.
 


**Note:** Beware of concealed wiring and piping when cutting through the roof.
8. Suspend the pipe(s) through center of hole using field supplied metal strapping or equivalent support materials as shown in **Figure 16**.

9. Slide a roof boot or equivalent flashing over the pipe and secure roof boot or equivalent flashing to roof (see **Figure 16**) and seal around the flashing.
10. Install the factory supplied intake air and/or vent termination(s) using field supplied pipe and one field supplied 90° elbow as shown in **Figure 16**. The short section of pipe that connects between the field supplied 90° elbow and the factory supplied termination must not be excessive in length. The exposed portion of this pipe shall be no more than 5 cm (2 inches). See **Figure 16**.



**Figure 17. Vertical Termination(s) Flat Roof Clearance - Intake Air and/or Vent (Exhaust)**

11. Return to **Power Vent Installation** (page 22) or **Direct Vent Installation** (page 22) to complete the installation of the intake air and/or vent piping between the termination(s) and the water heater.



**Figure 18. Vertical Termination - Direct Vent, Standard Terminations**




## SIDEWALL TERMINATION INSTALLATION

1. Determine the location for the termination(s).
2. If installing only vent (exhaust) piping in a Power Vent configuration through a sidewall; ensure that all exterior sidewall clearance requirements for the termination, shown in **Figure 27** (page 28), are being maintained. These clearances and those cited by local and national codes must be maintained.
3. If installing both intake air and vent piping in a Direct Vent configuration through a sidewall; ensure that all exterior sidewall clearance requirements for the terminations, shown in **Figure 28** (page 29), for the vent and intake air termination are being maintained. These clearances and those cited by local and national codes must be maintained.
4. If installing both an intake air and vent termination in a Direct Vent configuration through a sidewall there must be a minimum of 60 cm (24 inches) separation, measured on vertical center line, between the intake air and vent terminations. See **Figure 19**.

**Note:** In colder climates this separation should be increased to at least 122 cm (48 inches) between the intake air and vent termination or any other appliance vent that discharges moisture-laden air such as clothes dryers. This will reduce possibility of frost over from side winds blowing exhaust vapors to the intake air termination and is recommended for Canadian installations.

5. If installing both intake air and vent terminations in a Direct Vent configuration through a sidewall the intake air and vent terminations must be installed at the same elevation measured on horizontal center line - see **Figure 19**.



**Figure 19. Sidewall Termination - Direct Vent**

6. When the intake air and/or vent piping from multiple water heaters will terminate at the same location through a sidewall, the vent terminations can be grouped together in close proximity - 0 cm (0 inches)/touching. The intake air terminations can also be grouped together in close proximity - 0 cm (0 inches)/touching.

However, the distance between the closest vent and intake air terminations must be a minimum of 60 cm (24 inches). In colder climates this separation should be increased to at least 122 cm (48 inches). See **Figure 19**.


7. Cut an 18 cm (7 inch) diameter hole for six-inch pipe where the pipe(s) will pass through the wall.

**Note:** Beware of concealed wiring and piping when cutting through the wall.

8. Cut a length(s) of pipe being installed 8.9 cm (3.5 inches) to 24.1 cm (9.5 inches) longer than the wall thickness at the opening. See **Figure 20**.

**Note:** Vent Termination – exhaust gases of this water heater are less than 60 °C (140 °F). In cold climates water vapor in the exhaust gases will condense into a cloud of vapor where the vent exits the building. This vapor can gradually discolor exterior building surfaces. The vent termination should be located where this vapor cloud and potential discoloration are not a concern. Extending the exposed vent piping up to a maximum of 6 inches (15.2 cm) from the wall helps vapor from being trapped along a building's face. To avoid this problem, the vent can also be terminated vertically through the roof. See **Vertical Termination Installation** (page 23).

9. Cement the intake air and/or vent termination to the section(s) of pipe cut to length in the above Step.
10. Slide the included metal wall plate(s) over the pipe(s) to stop against the intake air and/or vent termination. Place some silicone caulking (field supplied) on the back of the wall plate(s) to secure it to the wall.
11. Working from outside, slide the pipe and termination(s) assembled in the above steps through the wall. Ensure the termination(s) is pointed down towards the ground. See **Figure 20**.



**Figure 20. Sidewall Termination Installation**

12. Place a bead of silicone caulking (field supplied) around the gap between the installed pipe(s) and the wall. Apply enough to fill the gap between the pipe(s) and wall.
13. Press the wall plate flush against the outside wall.
14. Working from the inside apply enough silicone caulking on the back of the interior wall plate(s) to hold it in place and slide the wall plate over the installed pipe(s).
15. Install a coupling to the end of the pipe(s) inside the building. Before the silicone caulking has time to completely set go outside the building and ensure the termination(s) is still pointing down towards the ground. See **Figure 20**.
16. Return to **Power Vent Installation** (page 22) or **Direct Vent Installation** (page 22) to complete the installation of the intake air and/or vent piping between the termination(s) and the water heater.

## POLYPROPYLENE INSTALLATIONS

The water heaters covered by this manual have been approved to be installed with Polypropylene vent material as shown in **Table 7** and **Table 8**. The approved application of single wall, non-flexible, non-concentric Polypropylene vent material is offered by two specific manufacturers (Centrotherm ECO Systems and DuraVent Polypropylene). These listed products must be installed by following the vent manufacturer's instructions. See **Table 7** to determine the maximum pipe length and number of elbows that can be used.

Insulation should not be used on Polypropylene venting materials. The use of insulation will cause increased vent wall temperatures, which could result in vent pipe failure.

Use only the adapters and vent system listed in Tables below. DO NOT mix vent systems of different types or manufacturers. Failure to comply could result in severe personal injury, death, or substantial property damage.

Installations must comply with applicable national, state, and local codes. For Canadian installation, Polypropylene vent must be listed as a **ULC-S636** approved system. If Polypropylene vent is not required by your local code, you may use either PVC or CPVC pipes for your water heater that allows non-metallic venting material installations.

Polypropylene vent systems do not use cement to connect the pipe and elbow sections but use a push together gasket seal method. Do not attempt to connect Polypropylene with sealant cement. All vent connections MUST be secured by the vent manufacturer's joint connector. The installer must use a specific vent starter adapter at the flue connection. The adapter is supplied by the vent manufacturer to adapt to its vent system.

In order to be in full compliance with UL 1738 or ULC-S636 and to meet the requirements of the water heater manufacturer, you must use the metal joint connector rings, available from the Polypropylene vent manufacturer, to stiffen the joints of six-inch diameter pipes.

Table 7. M & G DuraVent PolyPro Vent System Components					
Nominal Pipe Diameter	Flue Outlet Adapter	Adapter Connector	Ring Connector	90 Degree Elbow	Vent Material
6"	300153	PPS-PACL	6PPS-LBC	6PPS-E90	PPS

Table 8. Centrotherm InnoFlue SW Vent System Components					
Nominal Pipe Diameter	Flue Outlet Adapter	Adapter Connector	Ring Connector	90 Degree Elbow	Vent Material
6"	ISAAL0606-EXT	IAFC06	IANS06	ISEL0687	Polypropylene

## AL29-4C® VENT INSTALLATIONS

(AL29-4C® is a registered trademark of Allegheny Technologies, Inc.)

The water heaters covered by this manual are approved to be installed with AL29-4C® stainless steel vent material using parts from the manufacturers listed in **Table 9** and **Table 10** below. These listed systems must be installed using the vent manufacturer's instructions including their listed clearances to combustible and noncombustible materials. Use **Table 9** and **Table 10** below to find the appropriate equivalent linear vent lengths for the AL29-4C® elbows.

**Note:** The equivalent lengths of the AL29-4C® elbows are different than those from smooth walled plastic vents. Consult **Table 9** and **Table 10** for the correct equivalent linear vent lengths.

Listed vent systems composed of AL29-4C® must not mix parts from the different manufacturers. The joints of these products are sealed by internal gaskets. Do not use any other type of sealant. When assembling these vent systems, follow the vent manufacturer's instructions for cleaning and lubricating the joints, if required. Each section must be locked together using the method supplied by the vent manufacturer.

The water heaters covered by this manual are approved to be installed using the approved vent terminations shown in this manual. This means that, the installer must use the adapter listed in **Table 9** and **Table 10** and a short piece of PVC pipe to complete the end of the vent system with an approved termination. In Canada, the PVC pipe length must be listed to ULC636.

Table 9. HeatFab Saf-T Vent AL29-4C® Vent System Parts							
Diameter	Flue Outlet Adapter	*Straight Pipe (3' Section)	45° Elbow	Equivalent Linear Length, 45° Elbow	90° Elbow	Equivalent Linear Length, 90° Elbow	Adapter to PVC
6"	9601 PVC	9607	9611	5 feet	9614	10 feet	9656CPVC

Table 10. DuraVent FasNSeal AL29-4C® Vent System Parts							
Diameter	Flue Outlet Adapter	*Straight Pipe (3' Section)	45° Elbow	Equivalent Linear Length, 45° Elbow	90° elbow	Equivalent Linear Length, 90° Elbow	Adapter to PVC
6"	810005225	FSVL3606	FSELB4506	5 feet	FSELB9006	10 feet	81005572

Consult vent manufacturer's catalog for other available lengths.

# VENTING ARRANGEMENTS




Figure 21. Power Vent Vertical




Figure 22. Power Vent Horizontal




Figure 23. Direct Vent Vertical




Figure 24. Direct Vent Horizontal




Figure 25. Direct Vent Vertical Vent Horizontal Intake




Figure 26. Direct Vent Horizontal Vent Vertical Intake

# TERMINATION CLEARANCES SIDEWALL POWER VENT




Figure 27. Power Vent Using Outside Air

Termination Clearances for Sidewall Power Vent			
	Type of Clearance	Canadian Installations <sup>1</sup>	US Installations <sup>2</sup>
A	Clearance above grade, veranda, porch, deck or balcony	12 inches (30 cm)	12 inches (30 cm)
B	Clearance to window or door that may be opened	<ul style="list-style-type: none"> <li>6 in (15 cm) for appliances ≤ 10,000 Btuh (3 kW)</li> <li>12 in (30 cm) for appliances &gt; 10,000 Btuh (3 kW) and ≤ 100,000 Btuh (30 kW),</li> <li>36 in (91 cm) for appliances &gt; 100,000 Btuh (30 kW)</li> </ul>	<ul style="list-style-type: none"> <li>6 in (15 cm) for appliances ≤ 10,000 Btuh (3 kW)</li> <li>9 in (23 cm) for appliances &gt; 10,000 Btuh (3 kW) and ≤ 50,000 Btuh (15 kW)</li> <li>12 in (30 cm) for appliances &gt; 50,000 Btuh (15 kW)</li> </ul>
C	Clearance to permanently closed window	12 inches (30 cm)*	12 inches (30 cm)*
D	Vertical clearance to ventilated soffit located above the terminal within a horizontal distance of 2 feet (61 cm) from the center line of the terminal	12 inches (30 cm)*	12 inches (30 cm)*
E	Clearance to unventilated soffit	12 inches (30 cm)*	12 inches (30 cm)*
F	Clearance to outside corner	2 feet (60 cm)*	2 feet (60 cm)*
G	Clearance to inside corner	18 inches (45 cm)*	18 inches (45 cm)*

Termination Clearances for Sidewall Power Vent			
	Type of Clearance	Canadian Installations <sup>1</sup>	US Installations <sup>2</sup>
H	Clearance to each side of center line extended above meter/regulator assembly	3 ft (91 cm) within a height of 15 ft (4.6 m)	Clearance in accordance with local installation codes and the requirements of the gas supplier
I	Clearance to service regulator vent outlet	3 ft (91 cm)	Clearance in accordance with local installation codes and the requirements of the gas supplier
J	Clearance to a non mechanical air supply inlet into building or combustion air inlet to any other appliance	<ul style="list-style-type: none"> <li>6 in (15 cm) for appliances ≤ 10,000 Btuh (3 kW)</li> <li>12 in (30 cm) for appliances &gt; 10,000 Btuh (3 kW) and ≤ 100,000 Btuh (30 kW)</li> <li>36 in (91 cm) for appliances &gt; 100,000 Btuh (30 kW)</li> </ul>	<ul style="list-style-type: none"> <li>6 in (15 cm) for appliances ≤ 10,000 Btuh (3 kW)</li> <li>9 in (23 cm) for appliances &gt; 10,000 Btuh (3 kW) and ≤ 50,000 Btuh (15 kW)</li> <li>12 in (30 cm) for appliances &gt; 50,000 Btuh (15 kW)</li> </ul>
K	Clearance to a mechanical air supply inlet	6 feet (1.83 m)	3 feet (91 cm) above if within 10 feet (3 m) horizontally
L	Clearance above paved sidewalk or paved driveway located on public property	7 feet (2.13 m) †	7 feet (2.13 m) for mechanical draft systems (Category I appliances); vents for Category II and IV appliances cannot be located above public walkways or other areas where condensate or vapor can cause a nuisance or hazard
M	Clearance under veranda, porch, deck, or balcony	12 inches (30 cm) ‡	12 inches (30 cm) ‡

1. In accordance with the current *CSA B149.1, Natural Gas and Propane Installation Code*.

2. In accordance with the current *ANSI Z223.1/NFPA 54, National Fuel Gas Code*.

† A vent shall not terminate directly above a sidewalk or paved driveway that is located between two single family dwellings and serves both dwellings where it can cause hazardous frost or ice accumulations on adjacent property surfaces.

‡ Permitted only if veranda, porch, deck, or balcony is fully open on a minimum of two sides beneath the floor.

\* Clearance in accordance with local installation codes and the requirements of the gas supplier and the manufacturer's installation instructions

# TERMINATION CLEARANCES SIDEWALL DIRECT VENT




Figure 28. Sidewall Direct Vent Using Outside Air

Termination Clearances for Sidewall Direct Vent			
	Type of Clearance	Canadian Installations <sup>1</sup>	US Installations <sup>2</sup>
A	Clearance above grade, veranda, porch, deck or balcony	12 inches (30 cm)	12 inches (30 cm)
B	Clearance to window or door that may be opened	<ul style="list-style-type: none"> <li>6 in (15 cm) for appliances ≤ 10,000 Btuh (3 kW)</li> <li>12 in (30 cm) for appliances &gt; 10,000 Btuh (3 kW) and ≤ 100,000 Btuh (30 kW),</li> <li>36 in (91 cm) for appliances &gt; 100,000 Btuh (30 kW)</li> </ul>	<ul style="list-style-type: none"> <li>4 feet (1.2 m) below or to side of opening;</li> <li>1 foot (30 cm) above opening</li> </ul>
C	Clearance to permanently closed window	6 inches (15 cm)*	6 inches (15 cm)*
D	Vertical clearance to ventilated soffit located above the terminal within a horizontal distance of 2 feet (61 cm) from the center line of the terminal	12 inches (30 cm)	12 inches (30 cm)
E	Clearance to unventilated soffit	12 inches (30 cm)	12 inches (30 cm)
F	Clearance to outside corner	2 feet (60 cm)*	2 feet (60 cm)*
G	Clearance to inside corner	18 inches (45 cm)*	18 inches (45 cm)*

Termination Clearances for Sidewall Direct Vent			
	Type of Clearance	Canadian Installations <sup>1</sup>	US Installations <sup>2</sup>
H	Clearance to each side of center line extended above meter/regulator assembly	3 ft (91 cm) within a height 15 ft (4.6 m)	Clearance in accordance with local installation codes and the requirements of the gas supplier
I	Clearance to service regulator vent outlet	3 ft (1.83 m)	Clearance in accordance with local installation codes and the requirements of the gas supplier
J	Clearance to a non mechanical air supply inlet into building or combustion air inlet to any other appliance	<ul style="list-style-type: none"> <li>6 in (15 cm) for appliances ≤ 10,000 Btuh (3 kW)</li> <li>12 in (30 cm) for appliances &gt; 10,000 Btuh (3 kW) and ≤ 100,000 Btuh (30 kW)</li> <li>36 in (91 cm) for appliances &gt; 100,000 Btuh (30 kW)</li> </ul>	<ul style="list-style-type: none"> <li>4 feet (1.2 m) below or to side of opening;</li> <li>1 foot (30 cm) above opening</li> </ul>
K	Clearance to a mechanical air supply inlet	6 feet (1.83 m)	3 feet (91 cm) above if within 10 feet (3 m) horizontally
L	Clearance above paved sidewalk or paved driveway located on public property	7 feet (2.13 m)†	7 feet (2.13 m)
M	Clearance under veranda, porch, deck, or balcony	12 inches (30 cm) ‡	12 inches (30 cm) ‡

<sup>1</sup> In accordance with the current *CSA B149.1, Natural Gas and Propane Installation Code*.

† A vent shall not terminate directly above a sidewalk or paved driveway that is located between two single family dwellings and serves both dwellings. Where it can cause hazardous frost or ice accumulations on adjacent property surfaces.

‡ Permitted only if veranda, porch, deck, or balcony is fully open on a minimum of two sides beneath the floor.

\* Clearance in accordance with local installation codes and the requirements of the gas supplier and the manufacturer's installation instructions.

# WATER HEATER INSTALLATION

## CONDENSATE DRAIN INSTALLATION

Installation must conform with these instructions and local building codes.

Condensate neutralizer kits are available. Contact your distributor or Service Agency.

Field supplied materials required for installation include:

- Approved PVC cement and PVC primer.
- 1/2 inch PVC pipe - minimum length to equal the distance between the water heater and a suitable building drain.
- 1/2 inch PVC fittings (elbows, couplings and adapters) necessary to install a condensate drain line between the exhaust/condensate elbow assembly and a suitable building drain.
- Floor mounted standoffs to brace the drain line.

## INSTALLATION NOTES

1. The condensate drains from the water heater's covered by this instruction have pH levels between 4.3 and 5.0. Install a commercially available neutralizing kit if required by local codes. Lower pH levels are acidic. Do not connect a metal condensate drain line, such as copper pipe, to the water heater for this reason.
2. The field installed condensate drain line must not be less than 1/2 inch PVC in size. The condensate line must slope to an open drain.
3. Do not install an additional trap in the condensate drain piping.

## INSTALLATION INSTRUCTIONS

1. Ensure the water heater's Enable/Disable switch is in the "Disable" position.
2. Install a 1/2 inch PVC condensate drain line between the condensate drain connection on the heater and a suitable building drain.
3. Terminate the condensate drain piping with an elbow above the drain. Ensure that any discharge will exit the condensate drain line no more than 15.2 cm (6 inches) above a suitable building drain, or external to the building.


**Note:** In cold climates it is recommended the condensate drain be terminated at a suitable drain inside the building.

4. Ensure the condensate drain line is not elevated above the condensate drain connection on the exhaust/condensate elbow.
5. Brace the condensate drain line with floor mounted standoffs every three feet.
6. Ensure the condensate drains freely during start up. See **Start Up** (page 48).

## SUPPLY GAS LINE INSTALLATION

Contact your local gas utility company to ensure that adequate gas service is available and to review applicable installation codes for your area.

Be sure that the gas meter has sufficient capacity to supply the rated gas input of the water heater as well as the requirements of all other gas fired equipment supplied by the meter. If the gas meter is undersized, the gas company will have to install a properly sized gas meter.

	<b>WARNING</b>
	<b>Fire and Explosion Hazard</b> <ul style="list-style-type: none"><li>• Do not use water heater with any gas other than the gas shown on the rating label.</li><li>• Excessive gas pressure to gas valve can cause serious injury or death.</li><li>• Turn off gas lines during installation.</li><li>• Contact a qualified installer or service agency for installation and service.</li></ul>

Make sure gas supplied is same type listed on the water heater's rating label.

The water heaters covered in this manual are not intended for operation at higher than 14.0" W. C. (2.49 kPa) for natural and propane gas supply pressure. See **Table 4** (page 11). The water heaters covered in this manual require supply gas regulators to maintain required supply gas pressure. Exposure to higher gas supply pressure may cause damage to the gas controls which could result in fire or explosion. If overpressure has occurred such as through improper testing of gas lines or malfunction of the supply system the water heater's gas valve must be checked for safe operation by a Qualified Service Agency.

Ensure supply regulator vent lines and the safety vent valves are protected against blockage. These are components of the gas supply system, not the water heater. Vent blockage may occur during ice storms.

It is important to guard against gas valve fouling from contaminants in the gas ways. Such fouling may cause improper operation, fire or explosion. If copper supply lines are used they must be internally tinned and certified for gas service.




Figure 29. Supply Gas Line Installation

Ensure all gas pipe is clean on the inside before installation. To trap any dirt or foreign material in the gas supply line a sediment trap must be installed as shown in See **Figure 29**. The sediment trap must be readily accessible and not subject to freezing conditions. Install in accordance with the recommendations of the local gas utility company.

### SUPPLY GAS LINE SIZING

Minimum required supply gas line sizes are shown in **Table 2** (page 10). Depending on the developed equivalent length and/or the number of appliances connected to a common main, the size of supply gas lines may have to be increased.

### SUPPLY GAS LINE SIZING U. S. UNITS

Table 11. Supply Gas Line Sizing U.S. Units						
LENGTH IN FEET	NORMAL IRON PIPE SIZES (INCHES) INPUT IN THOUSANDS BTU/HR					
	1 1/4"	1 1/2"	2"	2 1/2"	3"	4"
10	1400	2100	3960	6300	11000	23000
20	950	1460	2750	4360	7700	15800
30	770	1180	2200	3520	6250	12800
40	660	990	1900	3000	5300	10900
50	580	900	1680	2650	4750	9700
60	530	810	1520	2400	4300	8800
70	490	750	1400	2250	3900	8100
80	460	690	1300	2050	3700	7500
90	430	650	1220	1950	3450	7200
100	400	620	1150	1850	3250	6700
125	360	550	1020	1650	2950	6000
150	325	500	950	1500	2650	5500
175	300	460	850	1370	2450	5000
200	N/A	430	800	1280	2280	4600

Size the supply/main gas line(s) in accordance with **Table 11** or **Table 12**. The values given in **Table 11** and **Table 12** are for straight lengths of iron pipe at 0.5" W. C. (125 Pa) pressure drop, which is considered normal for low pressure systems. Note that fittings such as elbows and tees will add to the pipe pressure drop.

Schedule 40 Steel or Wrought Iron Pipe is the preferred material for the gas line of this water heater. It is imperative to follow the sizing recommendations in the latest version of the **National Fuel Gas Code** if Corrugated Stainless Steel Tubing (CSST) is used as the gas line for this water heater.

### SUPPLY GAS LINE SIZING METRIC UNITS

Table 12. Supply Gas Line Sizing Metric Units						
LENGTH IN METERS	NORMAL IRON PIPE SIZES (INCHES) INPUT IN KW					
	1 1/4"	1 1/2"	2"	2 1/2"	3"	4"
3.0	410	615	1160	1845	3221	6735
6.1	278	428	805	1277	2255	4626
9.1	225	346	644	1031	1830	3748
12.2	193	290	556	878	1552	3192
15.2	170	264	492	776	1391	2840
18.3	155	237	445	703	1259	2577
21.3	143	220	410	659	1142	2372
24.4	135	202	381	600	1083	2196
27.4	126	190	357	571	1010	2108
30.5	117	182	337	542	952	1962
38.1	105	161	299	483	864	1757
45.7	95	146	278	439	776	1610
53.3	88	135	249	401	717	1464
61.0	N/A	126	234	375	688	1347


### GAS LINE CONNECTION

1. The water heaters covered by this manual are shipped from the factory with a two-inch supply gas connection. See **Table 1** (page 10). Connect the supply gas line to the water heater's 24 VAC Gas Valve in accordance with all applicable local and national code requirements.
2. Apply thread sealing compounds (pipe dope/ Teflon tape) sparingly and only to the male threads of the pipe joints. Do not apply sealing compound to the first two threads. Use pipe dope or Teflon tape marked as being resistant to the action of liquid petroleum (LP/propane) gases.
3. Use only a smooth jaw adjustable wrench (such as a monkey wrench) as a back up on the body of the 24 VAC Gas Valve when tightening the first pipe nipple into the body of the valve. **DO NOT** use a standard pipe wrench (Stillson wrench) with metal tooth jaws as this may permanently damage the valve.

4. Use a standard pipe wrench (Stillson wrench) as a back up on the first pipe nipple installed above when connecting other fittings and pipe in the supply gas line to prevent 24 VAC Gas Valve on water heater from twisting during installation.
5. To prevent damage, care must be taken not to apply too much torque when connecting the supply gas line to the water heater.
6. Install a sediment trap as shown in **Figure 29** (page 30).
7. Install a Main Gas Shutoff valve in the supply gas line as shown in **Figure 29** (page 30).

**Note:** If overheating occurs or the gas supply fails to shut off, turn off the Main Gas Shutoff valve to the water heater.

## GAS LINE LEAK TESTING

	<b>WARNING</b>
	<b>Fire and Explosion Hazard</b> <ul style="list-style-type: none"><li>• Use joint compound or Teflon tape compatible with propane gas.</li><li>• Leak test gas connections before placing water heater in operation.</li><li>• Disconnect gas piping at main gas shutoff valve before leak testing heater.</li><li>• Install sediment trap in accordance with NFPA 54 or CAN/CSA B149.1.</li></ul>

Any time work is done on the gas supply system perform a leak test to avoid the possibility of fire or explosion.

1. For test pressures exceeding 1/2 psi (3.45 kPa) disconnect the water heater and its Main Gas Shutoff Valve from the gas

## ELECTRICAL WIRING

All electrical work must be installed in accordance with the *National Electrical Code, ANSI/NFPA 70* or the *Canadian Electrical Code, CSA C22.1* and local requirements.

When installed, the water heater must be electrically grounded in accordance with local codes or, in the absence of local codes, with the *National Electrical Code, ANSI/NFPA 70* or the *Canadian Electrical Code, CSA C22.1*.

If any of the original wire as supplied with the water heater must be replaced, it must be replaced with 105°C rated wiring or its equivalent, except in the burner housing. In this case 200°C rated wire must be used.

### DEDICATED POWER WIRING AND BREAKERS

Dedicated power supply wires, ground wiring and dedicated circuit breakers often prevent electrical line noise and are required when installing the water heater.

**Note:** This water heater should not be connected to an electrical supply with a Ground Fault Circuit Interrupter (GFCI) or Arc Fault Circuit Interrupter (AFCI) with Integral GFCI protection as defined in *NFPA 70, CSA C22.1* and *UL 943*.

### POWER SUPPLY CONNECTIONS

Read the requirements for the *Power Supply* (page 13) before connecting power.

The 120 VAC hot wire from the power supply must connect to the black jumper wire or the “L1” terminal block location in the junction box and the 120 VAC neutral wire must connect to the white jumper wire or the “Neutral” terminal block location in the junction box for correct polarity. See *Figure 30* (page 32).

Power supply connections must be made as follows:

1. Turn off power at the water heater’s enable/disable switch and the breaker that supplies power to the water heater.
2. Remove the junction box cover. See *Figure 1* (page 8) for junction box location.
3. Connect the 120 VAC hot wire from the power supply to the black jumper wire or the terminal block location marked “L1” inside of the junction box located on top of the water heater.

supply piping system during testing. See *Figure 29* (page 30). The gas supply line must be capped when disconnected from the water heater.

2. For test pressures of 1/2 psi (3.45 kpa) or less, the water heater need not be disconnected, but must be isolated from the supply gas line by closing the Main Gas Shutoff Valve during testing.
3. Paint all supply gas line joints and connections upstream of the water heater with a rich soap and water solution to test for leaks. Bubbles indicate a gas leak. Do not use matches, candles, flame or other sources of ignition for this purpose.
4. Repair any leaks before placing the water heater in operation.

### PURGING

Gas line purging is required with new piping or systems in which air has entered. Purging should be performed per the current edition of *NFPA 54 the National Fuel Gas Code*.

If the black jumper wire is used, make the connection inside of the junction box with a properly sized wire nut and wrap electrical tape around the wire nut and wire end. See *Figure 30* (page 32) and the wiring diagram *Figure 41* (page 63).

4. Connect the 120 VAC neutral wire from the power supply to the white jumper wire or the terminal block location marked “Neutral” inside of the junction box located on top of the water heater. If the white jumper wire is used, make the connection inside of the tape around the wire nut and wire end. See *Figure 30* (page 32) and the wiring diagram *Figure 41* (page 63).

**Note:** If electrical connections are made directly to the terminal block remove the jumper wires before making connection.

Connect the ground wire from the power supply to the green jumper wire or the ground terminal location inside of the junction box located on top of the water heater. If the green jumper wire is used, make the connection inside of the junction box with a properly sized wire nut and wrap electrical tape around the wire nut and wire end. See the junction box *Figure 30* and wiring diagram *Figure 32* (page 36).

5. Replace the junction box cover when connections are complete.

**Note:** Do not apply power to the water heater before installation is complete and the water heater is filled with water.




Figure 30. Junction Box



## ENABLE/DISABLE CIRCUIT (FOR BUILDING MANAGEMENT SYSTEMS)

The water heaters covered in this manual are equipped with an enable/disable circuit for use with field supplied external supervisory controls such as time clocks or Building Management Systems. The enable/disable circuit may be used to disable heating operation during periods when the building is unoccupied or there is no demand for hotwater.

To use the enable/disable circuit it must first be activated by selecting the "Use External Enable" from the UIM. Field supplied wiring is then installed between the water heater's CCB and a set of "dry contacts" (no voltage or load) on the field supplied external control.

**Note:** The water heater's enable/disable circuit is a switching circuit only: Do not apply external voltage or connect any load (IE: relay coil) to this circuit. This will damage the CCB circuit board and is not covered under the limited warranty.

### CONNECTING AN EXTERNAL SUPERVISORY CONTROL

The enable/disable circuit is accessed from the CCB's J17 plug inside the CCB enclosure. See **Figure 1** (page 8) to locate the CCB enclosure and **Figure 40** (page 62) for the CCB layout.

Install field wiring to the enable/disable circuit:

1. Turn off power at the water heater's enable/disable switch and the breaker that supplies power to the water heater.
2. Locate the CCB enclosure.
3. Carefully remove the Temperature Probe connectors and CCB enclosure cover.
4. Locate pins 1 and 2 on the CCB J17 plug. See **Figure 40** (page 62).
5. Connect the two field supplied control wires to pins 1 and 2 on the CCB J17 plug.
6. Thread the control wires out of the CCB enclosure with the other wiring and carefully replace the CCB enclosure cover. Ensure all wiring is routed through the intended area provided for strain relief. Ensure no wiring is being pinched.
7. Reinstall the CCB enclosure cover.
8. Route the control wires inside the junction box on the top of the water heater. See **Figure 1** (page 8) to locate the junction box. Use an available knock-out to route the wires inside the junction box.
9. Install field supplied control wiring and conduit as required by national and local codes between the water heater's junction box and the external supervisory control. Connect the wiring from the external control to the control wires inside the junction box using wire nuts and electrical tape.
10. Connect the control wiring to a set of dry contacts on the external control. Follow the control manufacturer's instructions for making connections.
11. Restore power to the water heater.
12. From the water heaters UIM "Heater Information Screen" select "Use External Enable" and change to "Yes". See **Figure 1** (page 8) to locate the UIM.

**Note:** Whenever the external control opens the set of dry contacts used, water heating operation will be disabled. Whenever the external control closes the set of dry contacts used, water heating operation will be enabled. A diagonal line and circle appears over the thermometer icon on the UIM when water heating operation is disabled. See the Status Icons descriptions in **Table 14** (page 37).

**Note:** Ensure the water heater is protected from freezing temperatures when water heating operation is disabled. Damage to the water heater caused by freezing temperatures is not covered under the limited warranty.

## WATER LINE CONNECTIONS

The water piping installation must conform to these instructions and to all local and national code authority having jurisdiction. Good practice requires that all heavy piping be supported.

Read and observe all requirements in the following sections before installation of the water piping begins:

1. **Mixing Valves** (page 13).
2. See **Dish-washing Machines** (page 14).
3. **Temperature-Pressure Relief Valve** (page 15).
4. **Closed Water Systems** (page 14) and **Temperature-Pressure Relief Valve** (page 15).
5. For multiple water heater installation. See **Water Piping Diagrams** (page 65).

## WATER PIPING DIAGRAMS

This manual provides detailed water piping diagrams for typical methods of application for the water heaters. See **Water Piping Diagrams** (page 65).

The water heater may be installed with or without a separate storage tank. When used with a separate storage tank, the circulation may be either by gravity or by means of a circulating pump. When a circulating pump is used, it is important to note that the flow rate should be slow so that there will be a minimum of turbulence inside the water heater storage tank.

Adjust flow by throttling a full port ball valve installed in the circulating line on the outlet side of the pump. Never throttle flow on the suction side of a pump. See the **Water Piping Diagrams** (page 65).

**Note:** In addition to the factory installed Temperature-Pressure Relief Valve (T&P valve) on the water heater, each remote storage tank that may be installed and piped to a water heating appliance must also have its own properly sized, rated and approved Temperature-Pressure Relief Valve installed.

Call the toll free technical support phone number listed on the back cover of this manual for further assistance in sizing a T&P valve for remote storage tanks.


## THERMOMETERS (NOT SUPPLIED)

Thermometers are installed in the water piping system as a means of detecting the temperature of the hot water supply at critical points in the system. Field supplied thermometers should be obtained and installed. See **Water Piping Diagrams** (page 65).

## WATER (POTABLE) HEATING AND SPACE HEATING

1. All water piping components connected to the water heater that are for space heating applications shall be suitable for use with potable water.
2. Toxic chemicals, such as those used for boiler treatment, must NEVER be introduced into this system.
3. The water heaters covered in this manual may never be connected to any existing heating system or component(s) previously used with non-potable water heating appliance.
4. When the system requires water for space heating that exceed safe temperatures at domestic water fixtures a mixing valve must be installed. See *Mixing Valves* (page 13).
5. These water heaters cannot be used in space heating applications only.

### T&P VALVE DISCHARGE PIPE

	<b>WARNING</b>
	<b>Explosion Hazard</b> <ul style="list-style-type: none"><li>• Temperature-Pressure Relief Valve must comply with ANSI Z21.22- CSA 4.4 and ASME code.</li><li>• Properly sized temperature-pressure relief valve must be installed in opening provided.</li><li>• Can result in overheating and excessive tank pressure.</li><li>• Can cause serious injury or death.</li></ul>

This water heater is provided with a properly rated/sized and certified combination temperature - pressure (T&P) relief valve by the manufacturer. See *Temperature-Pressure Relief Valve* (page 15) for information on replacement and other requirements.

<b>CAUTION</b>
<b>Water Damage Hazard</b>
<ul style="list-style-type: none"><li>• Temperature-Pressure Relief Valve discharge pipe must terminate at adequate drain.</li></ul>

Install a discharge pipe between the T&P valve discharge opening and a suitable floor drain. Do not connect discharge piping directly to the drain unless a 30 cm (12 inches) air gap is provided. To prevent bodily injury, hazard to life, or property damage, the relief valve must be allowed to discharge water in adequate quantities should circumstances demand. If the discharge pipe is not connected to a drain or other suitable means, the water flow may cause property damage.

### T&P Valve Discharge Pipe Requirements:

- Shall not be smaller in size than the outlet pipe size of the valve, or have any reducing couplings or other restrictions.
- Shall not be plugged or blocked.
- Shall not be exposed to freezing temperatures.
- Shall be of material listed for hot water distribution.
- Shall be installed so as to allow complete drainage of both the Temperature-Pressure Relief Valve and the discharge pipe.
- Must terminate a maximum of six inches above a floor drain or external to the building. In cold climates, it is recommended that the discharge pipe be terminated at an adequate drain inside the building.
- Shall not have any valve or other obstruction between the relief valve and the drain.

### WATER LEAK PROTECTION

The water heaters covered by this manual have a water leak protection feature that senses the buildup of water in the vicinity of the appliance, setting off an alarm to alert the end user.

To use this feature, contact your local distributor or call Technical Support for assistance in ordering this kit. See the contact information label on the water heater.

Kit number 100302557

# TEMPERATURE REGULATION

## HIGH TEMPERATURE LIMIT CONTROL (ECO)


This water heater is equipped with an ECO (energy cut off) non adjustable high temperature limit switch. The ECO is a normally closed switch that opens (activates) on a rise in temperature.

The ECO is located inside the Upper Temperature Probe (two red wires). See *Figure 1* (page 8) for location. The ECO switch contacts will open when the water temperature reaches approximately 94°C (202°F) and close at approximately 60 °C (140 °F).

If the ECO activates (contacts open) due to abnormally high water temperatures in the storage tank the control system will immediately de-energize the 24 VAC Gas Valve and end the current heating cycle. The control system will “lock out” disabling further heating operation. The control system will display the “Energy Cut Out (ECO)” Fault message on the LCD screen. It is important that a Qualified Service Agent be contacted to determine the reason for the ECO activation before resetting the ECO. Once the reason has been determined and corrected the ECO can be reset as follows:

Should the ECO activate, the water temperature must drop below 60 °C (140 °F) before the control system can be reset. Once the water temperature has cooled below this point the power supply to the water heater must be turned off and on again to reset the control system.

## THERMOSTAT CONTROL



**⚠ DANGER**

Water temperature over 125°F (52°C) can cause severe burns instantly resulting in severe injury or death.

Children, the elderly and the physically or mentally disabled are at highest risk for scald injury.

Feel water before bathing or showering.

Temperature limiting devices such as mixing valves must be installed when required by codes and to ensure safe temperatures at fixtures.

Hot water temperatures required for automatic dishwasher and laundry use can cause scald burns resulting in serious personal injury and/or death. *Table 13* shows the approximate time-to-burn relationship for normal adult skin.

The temperature at which injury occurs varies with the person’s age and duration of exposure. The slower response time of children, the elderly or disabled persons increases the hazards to them. If anyone using hot water provided by the water heater being installed fits into one of these groups or if there is a local code or state law requiring a certain water temperature at the point of use, then special precautions must be taken.

In addition to using the lowest possible temperature setting that satisfies the demand of the application a mixing valve can be installed at the water heater or at the hot water taps to further reduce system water temperature. See *Figure 6* (page 14).

Never allow small children to use a hot water tap or draw their own bath water. Never leave a child or disabled person unattended in a bathtub or shower.

The water heater should be located in an area where the general public does not have access to set temperatures.

Setting the Operating Set Point at 49°C (120°F) will reduce risk of scalds. Some States require settings at specific lower temperatures.

Water Temperature °F (°C)	Time for 1st Degree Burn (Less Severe Burns)	Time for Permanent Burns 2nd & 3rd Degree (Most Severe Burns)
110 (43)	(normal shower temp.)	
116 (47)	(pain threshold)	
116 (47)	35 minutes	45 minutes
122 (50)	1 minute	5 minutes
131 (55)	5 seconds	25 seconds
140 (60)	2 seconds	5 seconds
149 (65)	1 second	2 seconds
154 (68)	instantaneous	1 second

(U.S. Government Memorandum, C.P.S.C., Peter L. Armstrong, Sept. 15, 1978)

The water heaters covered in this manual are equipped with an electronic control system to regulate the water temperature inside the storage tank. The control system senses temperature from two factory installed temperature probes, one installed in the top of the storage tank and one installed near the bottom. See *Figure 1* and *Figure 3* (page 8) for location.

The “Operating Set Point” is adjusted to regulate water temperature inside the storage tank. This is an adjustable user setting in the control system’s “Temperatures Menu.” This and all control system menus are accessed through the UIM (user interface module) located on the front of the water heater. See *Figure 31* (page 36).

The Operating Set Point is adjustable from 32°C (90°F) to 82°C (180°F). The factory setting is 49°C (120°F). See *Operating Set Point and Differential Adjustment* (page 39) for instructions on how to adjust the Operating Set Point and other user settings.

Set the Operating Set Point at the lowest setting which produces an acceptable hot water supply. This will always provide the most energy efficient operation.

## INTELLIGENT DEMAND RESPONSE

The water heaters covered by this manual utilize an Intelligent Demand Response (IDR) when the unit senses a large draw of hot water. It allows the water heater to reduce the pre-set differential to a lower setting so the appliance will have a more rapid response to the draw of hot water to support maintaining a steady state temperature at the outlet until the call for heat is satisfied.

This functionality is preset at the factory to enable this feature. If the feature is not required, it can be disabled in the field through the user interface module (UIM).

## FIRING RATE MODULATION

The water heaters covered by this manual are capable of modulating their firing rate. The central control board (CCB) monitors the water temperature in the tank and regulates the firing rate to achieve the target temperature setpoint. The firing rate is dictated by the hot water draw, proximity to the tank temperature setpoint, and various other temperature limitations.

## HIGH TEMPERATURE APPLICATIONS

Higher operating temperatures cause more wear on all water heaters and will decrease the life span of the water heater. Consider installing a small booster water heater for high temperature applications, such as commercial dishwashers, to raise the outlet temperature from the larger primary water heater to the desired point of use temperature. Contact your local distributor or call the technical support phone number listed on the back cover of this manual for further technical assistance.




Figure 31. User Interface Module Tank Temperature/Operating Setpoint Screen

## CONTROL SYSTEM OPERATION

### OVERVIEW

The water heaters covered in this manual are equipped with an electronic control system that regulates water temperature inside the storage tank. Heating cycles and ignition are managed by the control system. The ECO (energy cut out), flame sensor, recirculation flow switch, exhaust flue temperature sensor, pressure switches and temperature probes are monitored by the control system. The Combustion Blower, Spark Ignition Transformer, 24 Volt Gas Valve, 120 volt recirculator, and anode rods are all powered by the control system.

The main components of the control system are a UIM (user interface module) and a CCB (central control board). The UIM is located on the top front side of the water heater. The CCB is mounted inside a protective enclosure. This unit is equipped with an Enable/Disable switch. To operate unit, make sure the switch is set to Enable. See *Features and Components* (page 8) for location of these and all water heater components.




Figure 32. Control System Components

### CONTROL SYSTEM NAVIGATION

All operational information and user settings are displayed and accessed from the UIM. The UIM houses the control system's LCD Touch Display (liquid crystal display).

### WI-FI

The water heaters covered in this manual feature a wi-fi functionality that is enabled at the factory. If wi-fi is not required for installation, it can be disabled through the iCOMM screen from the main menu of the UIM.

### LOCKOUT FUNCTION

The water heaters covered in this manual feature a lockout functionality that is disabled at the factory by default. If the lockout functionality is required by the end user, the initial installer/contractor can access this functionality and enable it through the UIM.

### THE DESKTOP SCREEN

During normal operation the control system will display the "Desktop" screen on the LCD Touch Display which is the default screen. The control system will return to the Desktop screen when there are no active Fault or Alert conditions or when there has been no user input for several minutes.

- Manufacturer and water heater model information is displayed in Title Bar at the top of the Desktop screen. Menu titles are displayed in the Title Bar when navigating the control system menus.
- The first temperature shown on the Desktop screen, Tank Temperature, is the temperature of the water inside the water heater's storage tank.
- The second temperature shown on the Desktop screen is the Operating Set Point. The Operating Set Point is the temperature at which the control system will maintain the water inside the storage tank.
- Beneath the Operating Set Point is the "Status" line. The Status line shows the current operational state of the control system in real time. See *Table 15* (page 38) for a description of the various operational states.
- The Desktop screen also displays animated "Status Icons" to convey operational information. See *Table 14* (page 37) for descriptions of the Status Icons.




Figure 33. User Interface Module (UIM) Desktop Screen

**STATUS ICONS**

The Status Icons are displayed on the Desktop screen and convey operational and diagnostic information. The icons are described in the table below. See **Figure 33** (page 37). Ensure the water heater is properly grounded. Flame sensing requires

an adequate earth ground. If the water heater is not properly grounded, it will cause Ignition Failure. See **Electrical Connections** (page 52).

Table 14. Status Icons

Icon	Description
	Water temperature in the tank has fallen. Shaded area of the animated thermometer icon will rise and fall in response to water temperature in the storage tank as sensed from the Upper and Lower Temperature Probes. See <b>Figure 1</b> (page 8) and <b>Figure 3</b> (page 8) for location of Temperature Probes.
	Water temperature in the tank has reached the Operating Set Point. The control system enters the Standby mode.
	The control is unable to initiate a heating cycle. This will happen whenever a Fault condition is detected by the control system or when the Enable/Disable switch on front panel is in disable position or Building Management system Enable/Disable circuit is an open circuit. Display will read "Status: Water Heating Disabled". For more information see <b>Enable/Disable Circuit (For Building Management Systems)</b> (page 33).
	The Combustion Blower is being energized.
	The Spark Igniter is being energized. See <b>Figure 1</b> (page 8) and <b>Figure 3</b> (page 8) for location of the Spark Igniter.
	The 24 Volt Gas Valve is being energized.
	The control system has sensed flame at the Main Burner from the flame sensor. See <b>Sequence of Operation Flow Chart</b> (page 53) and <b>Figure 2</b> (page 8).
	The control system has declared a Fault condition and must be inspected/serviced by a Qualified Service Agent. Fault message details can be viewed in the Current Fault menu. Heating operation is disabled (lock out) until the condition that caused the Fault is corrected. Power to the water heater must be cycled off and on at the breaker to reset the control system. <b>Note:</b> Cycling power will not reset the control system if the condition that caused the Fault has not been corrected.
	The control system has declared an Alert condition and must be inspected/serviced by a Qualified Service Agent. The water heater will continue to operate during an Alert condition.

## OPERATING STATES

The current operational state of the water heater is displayed on the Desktop screen as the “Status.” The common operational states are described in the table below. See **Figure 33** (page 37) and **Electrical Connections** (page 52).

Table 15. Operating States	
Status	Description
Standby	The water heater is not in an active heating cycle. IE: the Tank Temperature is at or above the Operating Set Point.
Input Verification	The control system is conducting a diagnostic check at the beginning of a heating cycle.
Water Heating Disabled	A Fault condition is detected by the control, the Enable/Disable switch on front panel is in disable position, or the Building Management system Enable/Disable is an open circuit.
Pre-Purge	The Combustion Blower is energized to flush residual flue gases from the combustion chamber prior to ignition.
Spark Igniter Energized	The Spark Igniter is energized.
Ignition Activation	The 24 Volt Gas Valve is energized and opens to allow fuel gas to flow to the Main Burner.
Ignition Verification	The control system is monitoring the flame sensor for the required minimum flame sensing current. Ensure the water heater is properly grounded. Flame sensing requires an adequate earth ground. If the water heater is not properly grounded it will cause Ignition Failure.
Inter-Purge	The Combustion Blower is energized to flush residual fuel gas from the combustion chamber after a failed ignition attempt.
Heating	Ignition was successful, flame sensing current has been established. The water in the storage tank is being heated.
Post-Purge	The Combustion Blower is energized to flush residual flue gases from the combustion chamber at the end of a heating cycle.
Fault	The control system has detected a Fault condition. Heating operation is disabled until the Fault condition is corrected. Power to the water heater must be cycled off and on at the breaker to reset the control system.  <b>Note:</b> Cycling power will not reset the control system if the condition that caused the Fault has not been corrected.

## CONTROL SYSTEM MENUS

From the Desktop screen pressing “Menu” on the LCD Touch Display will display the “Main Menu” this is where all control system menus are located. The table below describes the control system menus.

Table 16. Control System Menus	
Menu	Description
Temperatures	Most commonly accessed menu. Contains the Operating Set Point and Differential user settings.
Heater Status	This menu displays the current state of all pressure switches and the ECO (open/closed). The on/off status of the Combustion Blower, gas valve, Spark Igniter, flame sensor and other monitored water heater components are displayed in this menu.
Display Settings	Temperature units (°F or °C), the LCD appearance (brightness/contrast) and backlight delay user adjustable settings are located in this menu.
iCOMM	Displays iCOMM connection information.
Network Interface	Displays the Network Address information.
Heater Information	Elapsed time of operation, total heating cycle time, heating cycle count, heating on time along with UIM and CCB software revisions can be viewed in this menu.
Current Fault	Displays any current Alert or Fault messages.
Fault History	This control system menu retains a list of the last nine (9) Fault and Alert messages with a time stamp. The newest event will replace the oldest. Faults will clear after 30 days.
Fault Occurrence	This control system menu retains a running total of how many times each Fault condition has occurred since the water heater was first installed. The data does not clear and cannot be reset.
Restore Factory Defaults	This control system feature allows the user to restore control system user settings to their factory default settings. Display Settings preferences ARE NOT changed when factory defaults are restored.

Table 16. Control System Menus

Menu	Description
Help Screens	Text based operational and user information explaining how to change user settings, navigate the control system menus and icon descriptions.

## USER SETTINGS & CONTROL SYSTEM MENUS

### TEMPERATURES MENU

#### Operating Set Point and Differential Adjustment

The Operating Set Point is adjustable from 42°C (90°F) to 82°C (180°F). The factory setting is 49°C (120°F). The Differential is adjustable from 2° to 20°. The factory setting is 8°. These user settings are accessed from the Temperatures menu. The following instructions will explain how to adjust these settings and navigate the control system menus.

When the water temperature sensed by the control system from the Temperature Probes reaches the Operating Set Point the

control system will end the heating cycle. A heating cycle will be activated again when the sensed water temperature drops below the Operating Set Point minus the Differential setting.

**Note:** Lower Differential settings may cause excessive heating cycles (short-cycling) which can cause premature failure of heater components. Set the Differential at the highest setting which produces an acceptable hot water supply. Set the Operating Set Point to the lowest setting which produces an acceptable hot water supply for most efficient use.

Temperatures Menu	
Description/Action	Display
From the Desktop screen, press MENU. The "Main Menu" screen will be displayed.	
The Main Menu is where all control system menus are listed. See <b>Table 16</b> (page 38) for a complete list and description of control system menus. Use the Up and Down slidebar to view all control system menus from the Main Menu.  Press "Temperatures" to access the Temperature menu.	
Press Operating Setpoint to access the temperature setpoint menu.  Press "CHANGE" to activate the adjustment mode for this menu item.  <b>Note:</b> Higher Temperature settings increase wear and operating costs. Set the Operating Set Point to the lowest setting which produces an acceptable hot water supply. This will always provide the most energy efficient operation and longer life.	

Temperatures Menu																	
Description/Action	Display																
<p>Use the "+" and "-" Buttons to change the current setting.</p> <p>Press "ACCEPT" to save the new setting. Press "BACK" to discard changes and return to the previously saved setting.</p> <p><b>Note:</b> Use this procedure to change the Differential setting and other adjustable user settings in the control system menus.</p>	<table border="1"> <tr> <td colspan="2"><b>Operating Setpoint</b></td> <td rowspan="2">+</td> </tr> <tr> <td colspan="2">120°F</td> </tr> <tr> <td>MIN 90°F</td> <td>MAX 180°F</td> <td rowspan="2">-</td> </tr> <tr> <td>ACCEPT</td> <td>BACK</td> </tr> </table>	<b>Operating Setpoint</b>		+	120°F		MIN 90°F	MAX 180°F	-	ACCEPT	BACK						
<b>Operating Setpoint</b>		+															
120°F																	
MIN 90°F	MAX 180°F	-															
ACCEPT	BACK																
<ul style="list-style-type: none"> <li>• <b>Differential Mode</b> - Operating mode with an Intelligent Demand Response (IDR). This mode allows the water heater to reduce preset differential to a lower setting so the appliance will more rapidly respond to large draws to maintain water outlet temperature. This mode is enabled at the factory by default, but can be disabled in the field if required.</li> <li>• <b>Differential</b> - Adjustable user setting that changes the tank temperature differential with a range of 2° to 20°F. The factory setting is 8°F.</li> <li>• <b>Tank Temperature</b> - Non adjustable. Control system sensed temperature (averaged from upper &amp; lower temperature probes).</li> <li>• <b>Tank Probe Offset</b> - adjustable user setting, range -5° to +5° (factory setting 0°).</li> </ul> <p><b>Note:</b> These settings should only be used if hot water supply temperature varies greatly from the Operating Set Point setting.</p> <ul style="list-style-type: none"> <li>• The Tank Probe Offset is used to calibrate control system temperature sensing. This can improve the precision of temperature control in the storage tank and at points of use. This feature can also be used to compensate for building recirculation loops (hot water returning to the storage tank) that may cause the heating cycles to terminate prematurely.</li> <li>• Example: If the current temperature from a temperature probe is 49°C (120°F) and the Offset setting is adjusted to a value other than 0°, the control system would calibrate or "offset" the sensed temperature from the probe and the averaged tank temperature. Heating cycles would be activated and deactivated based on the calibrated (offset) temperature. A -5° setting results in +5° hotter water.</li> <li>• These settings are adjusted as described in <i>Operating Set Point and Differential Adjustment</i> (page 39).</li> </ul>	<table border="1"> <tr> <td colspan="2"><b>Temperatures</b></td> </tr> <tr> <td>Operating Setpoint</td> <td>120°F &gt; ▲</td> </tr> <tr> <td>Differential Mode</td> <td>Auto &gt; ■</td> </tr> <tr> <td>Differential</td> <td>8°F &gt; ■</td> </tr> <tr> <td>Tank Temperature</td> <td>120°F</td> </tr> <tr> <td>Flue Temperature</td> <td>90°F</td> </tr> <tr> <td>Tank Probe Offset</td> <td>0°F &gt; ▼</td> </tr> <tr> <td>BACK</td> <td>HELP</td> </tr> </table>	<b>Temperatures</b>		Operating Setpoint	120°F > ▲	Differential Mode	Auto > ■	Differential	8°F > ■	Tank Temperature	120°F	Flue Temperature	90°F	Tank Probe Offset	0°F > ▼	BACK	HELP
<b>Temperatures</b>																	
Operating Setpoint	120°F > ▲																
Differential Mode	Auto > ■																
Differential	8°F > ■																
Tank Temperature	120°F																
Flue Temperature	90°F																
Tank Probe Offset	0°F > ▼																
BACK	HELP																




**ICOMM MENU**

iCOMM Screen																																	
Description/Action	Display																																
<p><b>Wi-fi Status</b> - displays status of wi-fi connection.  <b>Ethernet</b> - displays status of Ethernet connection.  <b>iCOMM Server</b> - displays status the iCOMM server.  <b>Wi-fi MAC</b> - displays the wi-fi MAC number.  <b>Ethernet MAC</b> - displays the Ethernet MAC number.  <b>DSN</b> - displays the Device Serial Number (DSN). Used for registration of the heater.  <b>Wi-fi Strength</b> - displays wi-fi signal strength as a series of bars.  <b>Wi-fi Strength</b> - displays wi-fi signal strength dBm units.  <b>Wi-fi</b> - Wi-fi functionality is enabled at the factory. In the bottom portion of the menu, the wi-fi can be disabled by selecting the <b>Enabled&gt;</b> marker and selecting the <b>Disable</b> option. This is the only item on this screen that can be adjusted. The other items are for view and information purposes only.</p>	<div style="text-align: center; border: 1px solid black; padding: 5px;"> <p><b>Top of Menu</b></p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="background-color: #333; color: white; text-align: center;">iCOMM</th> </tr> </thead> <tbody> <tr> <td>Wi-Fi Status</td> <td style="text-align: right;">Enabled ▲</td> </tr> <tr> <td>Ethernet</td> <td style="text-align: right;">Not Connected</td> </tr> <tr> <td>iCOMM Server</td> <td style="text-align: right;">Not Connected</td> </tr> <tr> <td>Wi-Fi MAC</td> <td style="text-align: right;">A408EA514209</td> </tr> <tr> <td>Ethernet MAC</td> <td style="text-align: right;">0C84110004CD</td> </tr> <tr> <td>DSN</td> <td style="text-align: right;">AC000W000657938 ▼</td> </tr> <tr> <td style="text-align: center;">BACK</td> <td style="text-align: center;">HELP</td> </tr> </tbody> </table> </div> <div style="text-align: center; border: 1px solid black; padding: 5px; margin-top: 20px;"> <p><b>Bottom of Menu</b></p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="background-color: #333; color: white; text-align: center;">iCOMM</th> </tr> </thead> <tbody> <tr> <td>Wi-Fi MAC</td> <td style="text-align: right;">A408EA514209 ▲</td> </tr> <tr> <td>Ethernet MAC</td> <td style="text-align: right;">0C84110004CD</td> </tr> <tr> <td>DSN</td> <td style="text-align: right;">AC000W000657938</td> </tr> <tr> <td>Wi-Fi Strength</td> <td></td> </tr> <tr> <td>Wi-Fi Strength</td> <td style="text-align: right;">dBm</td> </tr> <tr> <td>Wi-Fi</td> <td style="text-align: right;">Enabled &gt; ▼</td> </tr> <tr> <td style="text-align: center;">BACK</td> <td style="text-align: center;">HELP</td> </tr> </tbody> </table> </div>	iCOMM		Wi-Fi Status	Enabled ▲	Ethernet	Not Connected	iCOMM Server	Not Connected	Wi-Fi MAC	A408EA514209	Ethernet MAC	0C84110004CD	DSN	AC000W000657938 ▼	BACK	HELP	iCOMM		Wi-Fi MAC	A408EA514209 ▲	Ethernet MAC	0C84110004CD	DSN	AC000W000657938	Wi-Fi Strength		Wi-Fi Strength	dBm	Wi-Fi	Enabled > ▼	BACK	HELP
iCOMM																																	
Wi-Fi Status	Enabled ▲																																
Ethernet	Not Connected																																
iCOMM Server	Not Connected																																
Wi-Fi MAC	A408EA514209																																
Ethernet MAC	0C84110004CD																																
DSN	AC000W000657938 ▼																																
BACK	HELP																																
iCOMM																																	
Wi-Fi MAC	A408EA514209 ▲																																
Ethernet MAC	0C84110004CD																																
DSN	AC000W000657938																																
Wi-Fi Strength																																	
Wi-Fi Strength	dBm																																
Wi-Fi	Enabled > ▼																																
BACK	HELP																																

# HEATER STATUS MENU

Heater Status Menu																																																																																		
Description/Action	Display																																																																																	
<p>Press Heater Status from the Main Menu to enter this menu. This menu contains non adjustable operational information. Use the sidebar to navigate the menu.</p> <ul style="list-style-type: none"> <li>• <b>Status</b> - displays the current Operating State. See <b>Table 15</b> (page 38).</li> <li>• <b>ECO Contact, Low Gas PS, Blocked Inlet PS, Blocked Outlet PS</b>, - displays the current state of the switch contacts; open or closed.</li> <li>• <b>Igniter On, Gas Valve On</b> - displays whether or not the control system is currently energizing these water heater components; yes = energized, no = de-energized.</li> <li>• <b>Flame Detected</b> - displays whether or not the control system has detected Main Burner flame during ignition from the flame sensor.</li> <li>• <b>Blower RPM CMD</b> – displays the controls commanded blower rpms.</li> <li>• <b>Blower RPM</b> – displays the actual blower rpms.</li> <li>• <b>Anode Current, Anode Tank Voltage, Anode Drive Voltage</b> – displays the powered anodes current and voltage levels.</li> </ul> <p><b>Note:</b> Menu displays shown are for informational purposes only. The actual heater display will vary dependent upon the operational state of the water heater.</p>	<div style="text-align: center;"> <p><b>Top of Menu</b></p> <table border="1"> <thead> <tr> <th colspan="3">Heater Status</th> </tr> </thead> <tbody> <tr> <td>Status:</td> <td>Standby</td> <td>▲</td> </tr> <tr> <td>ECO Contact</td> <td>Closed</td> <td>■</td> </tr> <tr> <td>Low Gas PS</td> <td>Closed</td> <td>■</td> </tr> <tr> <td>Blocked Inlet PS</td> <td>Closed</td> <td>■</td> </tr> <tr> <td>Blocked Outlet PS</td> <td>Closed</td> <td>■</td> </tr> <tr> <td>Igniter On</td> <td>No</td> <td>▼</td> </tr> <tr> <td colspan="2"></td> <td>BACK      HELP</td> </tr> </tbody> </table> </div> <div style="text-align: center; margin-top: 20px;"> <p><b>Middle of Menu</b></p> <table border="1"> <thead> <tr> <th colspan="3">Heater Status</th> </tr> </thead> <tbody> <tr> <td>Gas Valve On</td> <td>No</td> <td>▲</td> </tr> <tr> <td>Flame Detected</td> <td>No</td> <td>■</td> </tr> <tr> <td>Blower RPM CMD</td> <td>0</td> <td>■</td> </tr> <tr> <td>Blower RPM</td> <td>0</td> <td>■</td> </tr> <tr> <td>Flue ECO</td> <td>Open</td> <td>■</td> </tr> <tr> <td>Pump</td> <td>Off</td> <td>■</td> </tr> <tr> <td>Anode Tank Voltage</td> <td>2.641V</td> <td>▼</td> </tr> <tr> <td colspan="2"></td> <td>BACK      HELP</td> </tr> </tbody> </table> </div> <div style="text-align: center; margin-top: 20px;"> <p><b>Bottom of Menu</b></p> <table border="1"> <thead> <tr> <th colspan="3">Heater Status</th> </tr> </thead> <tbody> <tr> <td>Anode CCB</td> <td></td> <td>▲</td> </tr> <tr> <td>Anode Current</td> <td>51.00mA</td> <td>■</td> </tr> <tr> <td>Anode Tank Voltage</td> <td>2.64V</td> <td>■</td> </tr> <tr> <td>Anode Drive Voltage</td> <td>3.59V</td> <td>■</td> </tr> <tr> <td>Anode Module 1:</td> <td></td> <td>■</td> </tr> <tr> <td>Anode Current</td> <td>25mA</td> <td>■</td> </tr> <tr> <td>Anode Tank Voltage</td> <td>3.5V</td> <td>■</td> </tr> <tr> <td>Anode Drive Voltage</td> <td>4.3V</td> <td>▼</td> </tr> <tr> <td colspan="2"></td> <td>BACK      HELP</td> </tr> </tbody> </table> </div>	Heater Status			Status:	Standby	▲	ECO Contact	Closed	■	Low Gas PS	Closed	■	Blocked Inlet PS	Closed	■	Blocked Outlet PS	Closed	■	Igniter On	No	▼			BACK      HELP	Heater Status			Gas Valve On	No	▲	Flame Detected	No	■	Blower RPM CMD	0	■	Blower RPM	0	■	Flue ECO	Open	■	Pump	Off	■	Anode Tank Voltage	2.641V	▼			BACK      HELP	Heater Status			Anode CCB		▲	Anode Current	51.00mA	■	Anode Tank Voltage	2.64V	■	Anode Drive Voltage	3.59V	■	Anode Module 1:		■	Anode Current	25mA	■	Anode Tank Voltage	3.5V	■	Anode Drive Voltage	4.3V	▼			BACK      HELP
Heater Status																																																																																		
Status:	Standby	▲																																																																																
ECO Contact	Closed	■																																																																																
Low Gas PS	Closed	■																																																																																
Blocked Inlet PS	Closed	■																																																																																
Blocked Outlet PS	Closed	■																																																																																
Igniter On	No	▼																																																																																
		BACK      HELP																																																																																
Heater Status																																																																																		
Gas Valve On	No	▲																																																																																
Flame Detected	No	■																																																																																
Blower RPM CMD	0	■																																																																																
Blower RPM	0	■																																																																																
Flue ECO	Open	■																																																																																
Pump	Off	■																																																																																
Anode Tank Voltage	2.641V	▼																																																																																
		BACK      HELP																																																																																
Heater Status																																																																																		
Anode CCB		▲																																																																																
Anode Current	51.00mA	■																																																																																
Anode Tank Voltage	2.64V	■																																																																																
Anode Drive Voltage	3.59V	■																																																																																
Anode Module 1:		■																																																																																
Anode Current	25mA	■																																																																																
Anode Tank Voltage	3.5V	■																																																																																
Anode Drive Voltage	4.3V	▼																																																																																
		BACK      HELP																																																																																


## DISPLAY SETTINGS

Description/Action	Display
<p>Press Display Settings from the Main Menu to enter this menu. This menu contains adjustable display options for viewing information on the UIM's LCD screen. Use the Slidebar to navigate the menu.</p> <ul style="list-style-type: none"> <li>• <b>Temperature Units</b> - Adjustable user setting that changes temperature units display to Celsius °C or Fahrenheit °F.</li> <li>• <b>Backlight Delay</b> - Adjustable user setting that determines how long the UIM's LCD backlight remains illuminated after a key has been pressed. Available settings are; Always Off, 10, 30 or 60 seconds and Always On.</li> <li>• <b>Contrast</b> - Adjustable user setting to adjust the UIM's LCD screen contrast between text and background.</li> </ul> <p><b>Note:</b> These settings are adjusted in the same way described for the <i>Operating Set Point and Differential Adjustment</i> (page 39).</p>	 <p>The screenshot shows a menu titled "Display Settings" with the following items:         <ul style="list-style-type: none"> <li>Temperature Units: °F &gt; (with an up arrow icon)</li> <li>Brightness: 5 &gt;</li> <li>Backlight Delay: 30s &gt;</li> <li>Language: English &gt;</li> </ul>         Below the menu items is a bar with two buttons: "BACK" and "HELP".       </p>


## HEATER INFORMATION

Description/Action	Display									
<p>Press Heater Information from the Main Menu to enter this menu. This menu contains non adjustable operational information.</p> <ul style="list-style-type: none"> <li>• <b>Elapsed Time</b> - Total accumulated time the control system (water heater) has been energized.</li> <li>• <b>Burner On Time</b> - Total accumulated time the control system has been in the heating operating state; burner run time.</li> <li>• <b>Total Cycle Count</b> - Total accumulated count of heating cycles.</li> <li>• <b>CCB Version</b> - Software version for central control board.</li> <li>• <b>Config CRC</b> - Verifies the configuration key matches the CCB programming.</li> <li>• <b>UIM Version</b> - Software version for user interface module.</li> <li>• <b>Use External Enable</b> - Enables/Disables the external enable circuit.</li> <li>• <b>External Enable Status</b> - Displays whether or not the external enable circuit has been activated.</li> <li>• <b>Ignition Trials</b> - Displays the number of ignition trials allowed.</li> </ul> <p><b>Note:</b> Historical data is stored in the configuration key. If this "key" is replaced during servicing the historical data will be lost. The data stored in the new configuration key will no longer reflect the entire history of the water heater. The configuration key should never be replaced unless directed by Technical Support.</p> <p>The Elapsed Time, Burner On Time and Cycle Count indicate age, usage and wear.</p> <p>If the Cycle Count per day is high (divide cycle count by days to determine cycles per day) or the cycle duration is short (determine burner on time total minutes, divide burner on time total minutes by cycle count) consider raising the Differential setting to avoid short cycling and excessive component wear. See <b>Operating Set Point and Differential Adjustment</b> (page 39).</p> <p>This historical data can also be used to assist facilities managers in forecasting planned replacement of equipment to help avoid lengthy and costly hot water supply interruptions.</p>	<div data-bbox="862 191 1433 527"> <p style="text-align: center;"><b>Heater Information</b></p> <p>Elapsed Time 0days 0hrs 43mins &gt; ▲</p> <p>Burner On Time 0days 0hrs 1mins</p> <p>Use External Enable No &gt; ■</p> <p>External Enable Status No</p> <p>Ignition Trials 3 tries &gt; ▼</p> <p>Modulation Enabled &gt; ▼</p> <table border="1" style="width: 100%; text-align: center;"> <tr> <td style="width: 33%;"></td> <td style="width: 33%;">BACK</td> <td style="width: 33%;"></td> </tr> </table> </div> <div data-bbox="862 590 1433 919"> <p style="text-align: center;"><b>Heater Information</b></p> <p>Ignition Trials 3 tries &gt; ▲</p> <p>Modulation Enabled &gt; ▼</p> <p>Total Cycles Counter 2 ■</p> <p>Ignition Failure Count 1 &gt; ▼</p> <p>Flame Loss Count 0 &gt; ▼</p> <p>CCB Version 3.17 &gt; ▼</p> <table border="1" style="width: 100%; text-align: center;"> <tr> <td style="width: 33%;"></td> <td style="width: 33%;">BACK</td> <td style="width: 33%;"></td> </tr> </table> </div> <div data-bbox="862 989 1433 1318"> <p style="text-align: center;"><b>Heater Information</b></p> <p>Ignition Failure Count 1 &gt; ▲</p> <p>Flame Loss Count 0</p> <p>CCB Version 3.17 ■</p> <p>Config CRC 0xD7A7 ■</p> <p>UIM Version 2.58</p> <p>Configuration Raw 0x510C ▼</p> <table border="1" style="width: 100%; text-align: center;"> <tr> <td style="width: 33%;"></td> <td style="width: 33%;">BACK</td> <td style="width: 33%;"></td> </tr> </table> </div>		BACK			BACK			BACK	
	BACK									
	BACK									
	BACK									


## CURRENT FAULT

Description/Action	Display
<p>Press Current Fault from the Main Menu to enter this menu. This menu contains non adjustable operational information. Use the Sidebar to navigate the menu.</p> <p>This menu contains the current Fault or Alert error message. The time the Fault or Alert message occurred appears directly below. A brief description of what causes the particular Fault or Alert condition appears below that. Pressing "ADVANCED" will give more detailed service information and a list of possible causes for the Fault or Alert condition. See <b>Fault and Alert Conditions</b> (page 55) for more detailed information and diagnostic procedures.</p> <p>If there is no Fault or Alert condition active this menu will not contain any information, "(none)" will be shown next to Current Fault in the Main menu.</p>	


## FAULT HISTORY

Description/Action	Display
<p>Press "Fault History" from the Main Menu to enter this menu. This menu contains non adjustable operational information. Use the Sidebar to navigate the menu.</p> <p>This menu contains a list of the last nine (9) Fault and Alert messages with a time stamp. The newest event will replace the oldest. Faults will clear after 30 days.</p> <p>Press the Fault to view details for each Fault or Alert message stored.</p>	

## FAULT OCCURRENCE




Description/Action	Display
<p>Press Fault Occurrence from the Main Menu to enter this menu. This menu contains non adjustable operational information. Use the Sidebar to navigate the menu.</p> <p>This menu contains a running total of how many times each Fault condition has occurred since the water heater was first installed.</p> <p><b>Note:</b> Historical data is stored in the configuration key. If this "key" is replaced during servicing the historical data will be lost. The data stored in the new configuration key will no longer reflect the entire history of the water heater.</p>	



## RESTORE FACTORY DEFAULTS

Description/Action	Display
<p>Press Restore Factory Defaults from the Main Menu to enter this menu.</p> <p>To restore the adjustable user settings to their factory default settings press "YES." The display will show text confirming the factory default settings have been restored.</p> <p>Press NO to exit the Restore Factory Defaults menu.</p>	

## SERVICE CONTACT INFORMATION

The control system has a discrete menu that installing contractors and/or service agents can access to enter contact information for their customers. This contact information will be displayed with all Fault and Alert messages.

Description/Action	Display
<p>From the Desktop Screen (see <i>Figure 33</i> (page 37)) press and hold down the middle (unmarked) Operational Button for 30 seconds and then release it. It is located between the "MENU" and "HELP" buttons.</p> <p>This will launch a discrete menu where personalized contact information can be entered.</p> <p>Using the Slidebar select (highlighted in black) the "Show Contact" menu item.</p> <p>Press "ACCEPT" to activate the adjustment mode for this parameter.</p>	
<p>Press the "+" and "-" Buttons to change the setting from "No" to "Yes" and press "ACCEPT" to save the new setting.</p> <p><b>Note:</b> The Access Code at the bottom of the Service Contact Information screen is for manufacturing engineering purposes only. There are no user settings or information accessed through this menu item.</p>	
<p>Press the "Change Contact Name" to enter this menu.</p>	

Description/Action	Display
<p>Press the "+", "-", "&lt;", and "&gt;" icons to enter your name or the name of your company.</p> <p>When finished press "ACCEPT" to save the new Contact Name. The control system will return to the discrete menu.</p> <p>Follow these same instructions to change the Contact Phone Number.</p>	
<p><b>Access Code</b> - Displays access code utilized to enable/disable screen lock.</p> <p><b>Enable Screen Lock</b> - Factory default set to No. When enabled, prevents access to any screen but the home screen and the Contact Information screen. This feature restricts access code to secure the water heater.</p> <p><b>Calibration Mode</b> -Used by service agent to adjust the gas valve for minimum and maximum fire rate.</p> <p><b>Calibration Speed</b> - Used by service agents to adjust blower speed to minimum fire rate if required.</p> <p><b>Note:</b> Calibration mode will reset back to No when the contact information screen is exited either by pressing the Back button or when the display times out. To be practical, the installer/field service agent should first go to the Display Setting screen from the Main Menu and set the Backlight Delay to 240 (On) before setting Calibration mode.</p>	<p style="text-align: center;"><b>Bottom of Menu</b></p> 

# START UP

## PRIOR TO START UP

Installation and start up of this water heater requires abilities and skills equivalent to that of a licensed tradesman in the field involved. See **Qualifications** (page 6).

DO NOT USE THIS APPLIANCE IF ANY PART HAS BEEN EXPOSED TO FLOODING OR WATER DAMAGE. Immediately call a qualified service agency to inspect the appliance and to make a determination on what steps should be taken next.

If the unit is exposed to the following, do not operate heater until all corrective steps have been made by a qualified service agency.

1. External fire.
2. Damage.
3. Firing without water.

Light the water heater in accordance with the **Lighting and Operation Instruction Label** (page 49) and on the water heater.

The water heaters covered by this manual are equipped with an electronic control system, which automatically sequences the Combustion Blower, pre and post purging of the combustion chamber, spark generator, 24 VAC Gas Valve, 120 VAC recirculator, Main Burner ignition, and flame sensing. See **Control System Operation** (page 36). The control system will lock out after three unsuccessful ignition attempts.

Before attempting start up, thoroughly study and familiarize yourself with the exact sequence of operation. See the written **Sequence of Operation** (page 52) and the **Sequence of Operation Flow Chart** (page 53).

Be certain that the water heater is full of water, that air is purged from the gas and water lines and that there are no leaks in the gas and water lines. Ensure all inlet water valves are open.

### FILLING THE WATER HEATER

Follow these steps to fill the water heater prior to start up.

1. Close the heater drain valve.
2. Open a nearby hot water faucet to permit the air in the system to escape.
3. Fully open the cold water inlet valve allowing the piping and water heater to fill with water.
4. Close the hot water faucet opened in Step 2 as water starts to flow.

## INITIAL START UP

### Required Test Equipment

- One U-tube manometer, recommended ranges; 0-14" W.C. (0--3.5 kPa) and 0-35" W.C. (0-8.7 kPa) or pressure gauges.
- One digital manometer can be used in place of U-tube manometers or pressure gauges. Recommended ranges; -14.00 to + 14.00" W.C. (0-3.5 kPa) resolution 0.01" W.C. and 0-35" W.C. (0-8.7 kPa) resolution 0.10" W.C.

**Note:** All test equipment must be acclimated to ambient temperature before calibration and use.

## PREPARATION

1. Using the control system menus, change the Operating Set Point to the lowest temperature setting. See **Operating Set Point and Differential Adjustment** (page 39).
2. Turn the water heater's Enable/Disable switch to the "Disable" position.
3. Close the Main Gas Shut Off Valve. See **Figure 29** (page 30).
4. Wait five (5) minutes for any residual gas to clear.
5. Connect manometer to the supply gas pressure port on the gas valve see **Figure 34**.

On the water heaters covered by this manual there are test ports for supply pressure readings on the gas valve. Remove the middle port plug with an Allen wrench and install the manometer sensing tubing.

6. Open the Main Gas Shutoff Valve.
7. Measure and record the supply gas pressure, this is a "static" supply gas pressure reading; while the water heater is not firing. Adjust supply gas pressure as necessary. See **Supply Gas Pressure Adjustment** (page 50).

**Note:** The manometer tubing should be purged before taking any readings.




Figure 34. Location of Gas Supply Pressure Test Port



## FOR YOUR SAFETY READ BEFORE LIGHTING




**WARNING:** If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.



**BEFORE OPERATING: ENTIRE SYSTEM MUST BE FILLED WITH WATER AND AIR PURGED FROM ALL LINES.**

- A. This appliance does not have a pilot. It is equipped with an ignition device which automatically lights the burner. **Do not try to light the burner by hand.**
- B. **BEFORE OPERATING** smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.
- WHAT TO DO IF YOU SMELL GAS**
- Do not try to light any appliance.
  - Do not touch any electric switch; do not use any phone in your building.
  - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
  - If you cannot reach your gas supplier, call the fire department.
- C. Use only your hand to push in the control buttons. Never use tools. If the control buttons will not push in, don't try to repair them, call a qualified service technician. Force or attempted repair may result in a fire or explosion.
- D. Do not use this appliance if any part has been under water. Immediately contact a qualified installer or service agency to replace a flooded water heater. Do not attempt to repair the unit. It must be replaced!

## OPERATING INSTRUCTIONS




1. **STOP!** Read the safety information above on this label.
2. Set the Enable/Disable switch on the control panel to the Enable position.
3. Set the thermostat to the lowest setting.
4. Set the Enable/Disable switch on the control panel to the Disable position.
5. This appliance is equipped with a device which automatically lights the burner. **DO NOT TRY TO LIGHT THE BURNER BY HAND.**
6. Wait five (5) minutes to clear out any gas. If you then smell gas, **STOP!** Follow "B" in the safety information above on this label. If you don't smell gas, go to the next step.
7. Turn on all electrical power to the appliance.
8. Set the Enable/Disable switch on the control panel to the Enable position.
9. Set the thermostat to the desired setting.
10. **CAUTION: Hotter water increases the risk of scald injury. Consult the instruction manual before changing temperature.**
10. If the appliance will not operate, follow the instructions "TO TURN OFF GAS TO APPLIANCE" and call your technician or gas supplier.
11. **WARNING: TURN OFF ALL ELECTRIC POWER BEFORE SERVICING.**

## TO TURN OFF GAS TO APPLIANCE

1. Set the thermostat to the lowest setting.
2. Set the Enable/Disable switch on the control panel to the Disable position.
3. Turn off all electrical power to the appliance if service is to be performed.

## SUPPLY GAS PRESSURE ADJUSTMENT

	<b>WARNING</b>
	<b>Fire and Explosion Hazard</b> <ul style="list-style-type: none"><li>• Do not use water heater with any gas other than the gas shown on the rating label.</li><li>• Excessive gas pressure to gas valve can cause serious injury or death.</li><li>• Turn off gas lines during installation.</li><li>• Contact a qualified installer or service agency for installation and service.</li></ul>

Supply gas pressure shall be measured while the water heater is not firing (static pressure) AND while the water heater is firing at full capacity (dynamic pressure).

If the supply gas pressure to the water heater is not between the required minimum and maximum values given in **Table 4** (page 11) adjust the supply gas regulator as necessary. Adjust the supply gas regulator(s) per the regulator manufacturer's instructions to achieve the required "static" and "dynamic" supply gas pressure.

### Multiple Appliance Installations:

In multiple water heater installations or in installations where the installed water heater(s) share a common gas supply main with other gas fired appliances; the supply gas pressures shall be measured at each water heater with all gas fired appliances connected to a common main firing at full capacity.

On multiple water heater installations the supply gas line regulators shall be adjusted to provide gas pressure to each water heater within the minimum and maximum supply pressure requirements listed in **Table 4** (page 11) with all gas fired appliances connected to a common gas main firing at full capacity.

**Note:** A pressure drop of more than 1.5" W. C. (0.37 kPa) when the Main Burner ignites is an indication of an inadequate supply of gas and can lead to ignition failure, rough starts and/or rough operation. If a drop of more than 1.5" W. C. (0.37 kPa) in supply gas pressure occurs when the Main Burner ignites, ensure the supply gas lines and regulator(s) are properly sized and installed. See **Supply Gas Regulator** and **Supply Gas Line Requirements** (page 13). See **Supply Gas Line Installation** (page 30) and **Supply Gas Regulator** (page 13). Ensure all requirements and installation instructions are maintained.

## CHECKING THE FIRING RATE

Follow these instructions to determine the actual firing rate of the water heater:

**Note:** The heaters covered by this manual are capable of modulating their firing rate. The firing rate should be checked with the heater operating at it's full firing rate.

1. Ensure there are no other gas fired appliances connected to the gas meter firing during this test.
2. Contact the gas supplier to determine the heating value, in Btu per cubic foot, of the gas supply.
3. Start the water heater and ensure it is firing.
4. Locate the gas meter serving the water heater.
5. Time how long (in seconds) it takes for one cubic foot of gas to be used while the water heater is firing with a stop watch.
6. Use the formula below to "clock" the gas meter and determine the actual firing rate of the water heater based on the heating value (Btu per cubic foot) of the gas supply:

$$\frac{3600}{T} \times H = \text{Btu/hr}$$

Example:

$$\frac{3600}{5.0} \times 1050 = 756,000 \text{ Btu/hr (221.6 kW)}$$

- 3600 = seconds in one hour.
- T = time, in seconds, to burn one cubic foot of gas.
- H = heating value of gas in Btu per cubic foot.
- Btu/hr = actual firing rate of the water heater.


**Note:** 1050 Btu per cubic foot is a standard value for natural gas. Standard propane gas Btu content is 2500 Btu per cubic foot. Btu values may change in certain areas and at high elevations. Check with the local gas utility company.


### TO TURN OFF GAS SUPPLY

1. Change the Operating Set Point to the lowest temperature setting. See **Operating Set Point and Differential Adjustment** (page 39).
2. When the water heater has completed its shut down sequence and enters the standby mode, turn the water heater's Enable/Disable switch to the "Disable" position. When in the "Disable" position the switch only removes electrical power from the gas valve so that water heating is disabled. The display, CCB, and other electrical components will still be energized and the display will read "Water Heating Disabled".
3. Close the Main Gas Shutoff Valve. See **Figure 29** (page 30).

## HIGH ALTITUDE INSTALLATIONS

The water heaters covered by this manual are certified for use without modification for altitudes up to 10,100 feet unnecessary to install high altitude orifices.

	<b>! WARNING</b>
	<b>Fire and Explosion Hazard</b>
	<ul style="list-style-type: none"><li>• Under no circumstances should the input exceed the rate shown on the water heater's rating label.</li><li>• Overfiring could result in fire or explosion.</li><li>• Gas and carbon monoxide detectors are available.</li></ul>

<b>! WARNING</b>	
<b>Breathing Hazard - Carbon Monoxide Gas</b>	
	<ul style="list-style-type: none"><li>• Under no circumstances should the input exceed the rate shown on the water heater's rating label.</li><li>• Overfiring could result in damage to the water heater and sooting.</li><li>• Gas and carbon monoxide detectors are available.</li></ul>
Breathing carbon monoxide can cause brain damage or death. Always read and understand instruction manual.	

**Note:** The actual firing rate of the water heater must not exceed the input rating on the water heater's rating label under any circumstances.

**Note:** Due to the input rating reduction at high altitudes, the output rating of the water heater is also reduced and should be compensated for in the sizing of the equipment.

# TROUBLESHOOTING

## INSTALLATION CHECKLIST

The list below represents some of the most critical installation requirements that, when overlooked, often result in operational problems, down time and needless parts replacement. This is not a complete list. Before performing any troubleshooting procedures use the list below to check for installation errors. Costs to correct installation errors are not covered under the limited warranty. Ensure all installation requirements and instructions in this manual have been maintained and followed.

### WATER HEATER LOCATION

1. Ensure proper clearances to combustibles are maintained and there is sufficient room to service the water heater. See **Clearance To Combustible Materials** (page 11).
2. Ensure the area is free of corrosive elements and flammable materials. See **Locating the Water Heater** (page 11).

### VENTING

1. Ensure the intake air and/or vent (exhaust) piping is the correct size for the installed length. See **Venting Requirements** (page 21).
2. Ensure the maximum equivalent feet of pipe has not been exceeded for the intake air and/or vent pipe. See **Maximum Equivalent Lengths** (page 21).
3. Ensure the maximum number of elbows has not been exceeded in the intake air and/or vent pipe. See **Venting Requirements** (page 21).
4. Ensure the intake air screen is removed from the intake air connection on the water heater when installing the water heater in a Direct Vent configuration. See **Figure 15** (page 23).
5. Ensure all exterior clearances for the intake air, vent, terminations are maintained. See the following as appropriate:
  - **Vertical Termination Installation** (page 23).
  - **Sidewall Termination Installation** (page 25).

These clearances and those cited by local and national codes must be maintained.

### GAS SUPPLY AND PIPING

1. Ensure a supply gas regulator has been installed for each water heater. See the requirements for a **Supply Gas Regulator** (page 13).
2. Ensure the supply gas line to each water heater meets the minimum supply gas line size requirements. See **Supply Gas Line Requirements** (page 13) and the **Supply Gas Line Installation** (page 30).

### CONDENSATE DRAIN

Ensure that the condensate drain is properly connected to the the water heater to prevent vent gases from escaping into the installed space and drains freely to a suitable floor drain. See **Figure 7** (page 16) and **Condensate Drain Installation** (page 30).

### ELECTRICAL CONNECTIONS

1. Ensure that the power supply connections to the water heater are polarity correct. See the requirements for the **Power Supply** (page 13) and **Electrical Wiring** (page 32).

2. Ensure that the water heater is properly grounded. Flame sensing requires an adequate earth ground. If the water heater is not properly grounded it will cause Ignition Failure.

### SEQUENCE OF OPERATION

Read the Sequence of Operation below before attempting to correct any operational problems. See **Features and Components** (page 8) for the location of various water heater components described below. See the **Sequence of Operation Flow Chart** (page 53) also.

1. When the control system is first powered, during boot up, it will display water heater model information during initialization. After a few moments the control system LCD which is part of the UIM (user interface module) will display the default screen known as the "Desktop" screen.
2. If the control system determines that the actual water temperature inside the tank is below the programmed Operating Set Point minus the Differential setting, a heating cycle is activated.
3. The control system then performs selected diagnostic system checks. This includes confirming that the recirculation flow switch is open and that the blocked exhaust, blocked intake and ECO (energy cut out) switch contacts are closed.
4. If all diagnostic checks are successfully passed, the control system energizes the Combustion Blower for pre-purge.
5. The control system energizes the spark ignition control.
6. The control system energizes the 24 VAC Gas Valve allowing gas to flow to the Main Burner.
7. The control system monitors the flame sensor to confirm a flame is present at the Main Burner. If a flame is not verified during the ignition trial period the control system will try for ignition up to two more times. If flame can not be verified after three trials for ignition, the control system will lock out and display the "Ignition Failure" Fault message.
8. If a flame is verified, the control system will de-energize the Spark Ignition Control, energize the recirculator, and enter the heating mode where it will continue heating the water until it reaches the Operating Set Point. At this point, the control system will de-energize the 24 VAC Gas Valve, de-energize the recirculator after a 5 second delay, and then enter the post-purge cycle (approximately 30 seconds).
9. The water heaters covered by this manual are capable of modulating their firing rate. The firing rate is dictated by the hot water draw and various other temperature limitations.
10. The Combustion Blower will run for the duration of the post-purge cycle to purge the water heater of all combustion gases. When the post-purge cycle is complete, the blower is de-energized and will coast to a stop.
11. The control system now enters the standby mode while continuing to monitor the internal storage tank water temperature and the state of other system devices. If the tank temperature drops below the Operating Set Point minus the Differential setting, the control will automatically return to Step 2 and repeat the operating cycle.

## SEQUENCE OF OPERATION FLOW CHART

Sequence is shown with Enable/Disable Switch in the Enable position





Figure 35. Sequence of Operation

## OPERATIONAL PROBLEMS

	 <b>WARNING</b>
	<p>Read and understand this instruction manual and the safety messages herein before installing, operating or servicing this water heater.</p>
	<p>Failure to follow these instructions and safety messages could result in death or serious injury.</p> <p>This manual must remain with the water heater.</p>

This section of the manual is intended to be an aid in correcting common operational problems, it is not all inclusive. The installer may be able to observe and correct certain problems which might arise when the water heater is first put into operation or when it is re-fired after a prolonged shutdown. However, only qualified service agents, as defined in **Qualifications** (page 6), using appropriate test equipment, should perform any service procedures on the water heater.

**Note:** Call the technical support phone number listed on the back cover of this manual for further technical assistance or to locate a qualified service agent in your area.



### INSTALLATION ERRORS

Operational problems on new installations are often the result of installation requirements that have been overlooked rather than failed components. IE: A “Low Gas Pressure” Fault condition is most often caused by low supply gas pressure rather than a defective Low Gas Pressure switch. Rough starting and rough operation are often caused by undersized supply gas lines and/or the absence of a supply gas regulator at the water heater.

Prior to performing any operational checks inspect the water heater installation to ensure all installation requirements and instructions have been maintained and followed. See the **Installation Checklist** on (page 52).

**Note:** Costs to correct installation errors are not covered under the limited warranty.



### ROUGH STARTING, ROUGH OPERATION

	 <b>WARNING</b>
	<b>Fire and Explosion Hazard</b>
	<ul style="list-style-type: none"> <li>Do not use water heater with any gas other than the gas shown on the rating label.</li> <li>Excessive gas pressure to gas valve can cause serious injury or death.</li> <li>Turn off gas lines during installation.</li> <li>Contact a qualified installer or service agency for installation and service.</li> </ul>

- Undersized supply gas line (low volume of supply gas). See **Supply Gas Line Requirements** (page 13).
- Supply gas regulator is not installed per installation requirements (erratic gas supply volume/pressures). See **Supply Gas Regulator** (page 13).
- Excessive supply gas pressure. See **Table 4** (page 11) and **Supply Gas Pressure Adjustment** (page 50).

- Vent (exhaust) gas recirculation at the vent and intake air pipe terminations on Direct Vent installations. See **Direct Vent Installation** (page 22).
- Excessive equivalent lengths of intake air and/or vent (exhaust) piping installed. See **Venting Requirements** (page 21).
- Debris clogging/blocking the intake air screen(s). See **Figure 15** (page 23) and **Figure 19** (page 25).
- Debris clogging/blocking the Main Burner. See **Figure 2** (page 8).

### MOMENTARY IGNITION

 <b>CAUTION</b>	
<b>Burn Hazard</b>	
	<ul style="list-style-type: none"> <li>The combustion chamber and burner sleeve and housing become very hot during operation.</li> <li>Do not reach into the burner housing or combustion chamber if the water heater is still hot.</li> <li>Allow the water heater to cool and always use gloves when handling the main burner.</li> </ul>

If the Main Burner ignites momentarily but does not sustain ignition allow the water heater to try to ignite up to two more times until control system locks out and the Ignition Failure Fault message is displayed on the control system’s LCD. If the water heater is experiencing rough starts, see **Rough Starting, Rough Operation** on this page. For momentary ignition problems without rough starting check the following:

- Undersized supply gas line (low volume of supply gas). See **Supply Gas Line Installation** (page 30).
- Supply gas regulator is not installed per installation requirements (erratic gas supply volume/pressures) . See **Supply Gas Regulator** (page 13).
- See the list of possible causes and things to check and repair for the Ignition Failure fault message in **Fault and Alert Conditions** (page 55).
- Debris clogging/blocking the intake air screen(s). See **Figure 15** (page 23) and **Figure 19** (page 25).
- Debris clogging/blocking the Main Burner. See **Figure 2** (page 8).

### NOT ENOUGH OR NO HOT WATER

- No power to the water heater, check breaker or fuses.
- Enable/Disable switch in “Disabled” position. Set to “Enable” to allow unit to operate.
- Hot water supply valve(s) to fixtures closed.
- Operating Set Point is set too low, Differential setting is set too high. See **Control System Operation** (page 36).
- Tank Probe Offset is causing the heating cycles to terminate prematurely. See **Temperatures Menu** (page 39).
- The heating capacity of the water heater has been exceeded, the water heater is unable to meet demand.
- Colder incoming water temperature lengthening the time required to heat water to desired temperature.

- Hot water piping leaks, open faucets, water heater drain valve leaking or open.
- Sediment or lime scale accumulation may be affecting water heater operation. See **Maintenance** (page 58) for sediment and lime scale removal procedures.
- Water heater not firing at full input rating. Check actual firing rate of the water heater. See **Checking the Firing Rate** (page 50).

**Note:** The water heaters covered by this manual are capable of modulating their firing rate. The firing rate is dictated by the hot water draw and various other temperature limitations.

#### WATER IS TOO HOT

- Operating Set Point is set too high. See **Operating Set Point and Differential Adjustment** (page 39).
- If installed check Thermostatic Mixing Valve settings.
- Tank Probe Offset setting improperly set. See **Temperatures Menu** (page 39).
- Lime build-up on temperature probes. Inspect and clean.
- Improper water piping. See **Water Piping Diagrams** (page 65).

#### NOISY OPERATION

- Sediment or lime scale accumulations can cause rumbling and pounding noises during heating cycles. See **Maintenance** (page 58) for sediment and lime scale removal procedures.
- Normal operating noise of electrical components; Combustion Blower, transformer hum, relay contact closure.

#### WATER LEAKAGE IS SUSPECTED

- Ensure the water heater drain valve is tightly closed.
- Check cleanout opening for leaks. See **Figure 1** (page 8).
- Check inlet/outlet water connections and system piping.
- Check the Temperature-Pressure Relief Valve.
- Excessive water temperature.
- Excessive water pressure.
- Defective Temperature-Pressure Relief Valve.

**Note:** Excessive water pressure is the most common cause of Temperature-Pressure Relief Valve leakage. Excessive water system pressure is most often caused by “thermal expansion” in a “closed system.” See **Closed Water Systems** (page 14) and **Temperature-Pressure Relief Valve** (page 15). The Temperature-Pressure Relief Valve is not intended for the constant relief of thermal expansion.

Temperature-Pressure Relief Valve leakage due to pressure build up in a closed system that does not have a thermal expansion tank installed is not covered under the limited warranty. Thermal expansion tanks must be installed on all closed water systems.

#### REPLACEMENT PARTS

Replacement parts may be ordered from the manufacturer, authorized service agencies or distributors. When ordering parts be sure to have the complete water heater Model Number, Serial Number and Series Number available. This information can be found on the rating label affixed to the water heater.

See the parts list included with the water heater from the factory for more information or call the parts department or technical

support phone number listed on the back cover of this manual for further assistance.

### FAULT AND ALERT CONDITIONS

#### FAULT CONDITIONS

When the control system declares a Fault condition it will display a Fault message on the control system’s LCD with an exclamation “!” mark. The control system will lock out and disable heating operation until the condition is corrected. The water heater must be serviced by a qualified service agent before operation can be restored.


#### ALERT CONDITIONS

When the control system declares an Alert condition it will display an Alert message on the control system’s LCD with a question “?” mark. The water heater will continue to operate during an Alert condition but the water heater must be serviced by a qualified service agent as soon as possible.

#### RESETTING CONTROL SYSTEM LOCK OUTS

To reset the control system from a lock out condition; turn the electrical power supply off for approximately 20 seconds and then back on. Keep in mind; if the condition that caused the Fault has not been corrected, the control system will continue to lock out.

#### DIAGNOSTIC CHECKS

<b>⚠ WARNING</b>	
	<p style="text-align: center;"><b>Electrical Shock Hazard</b></p> <ul style="list-style-type: none"> <li>• Turn off power at the branch circuit breaker serving the water heater before performing any service.</li> <li>• Label all wires prior to disconnecting when performing service. Wiring errors can cause improper and dangerous operation.</li> <li>• Verify proper operation after servicing.</li> <li>• Failure to follow these instructions can result in personal injury or death.</li> </ul>

The following section **Fault And Alert Messages** (page 56) lists some of the messages the control system will display on the LCD when there are operational problems. This is not a complete list. Along with each of the Fault and Alert messages described there will be a list of possible causes and things to check and repair.

Only qualified service agents, as defined in **Qualifications** (page 6), using appropriate test equipment, should perform any service procedures on the water heater.

**Note:** If you are not qualified and licensed or certified as required by the authority having jurisdiction to perform a given task do not attempt to perform any of the diagnostic or service procedures described in the following section.

If you do not understand the instructions in the following section do not attempt to perform any procedures.


Call the technical support phone number listed on the back cover of this manual for further technical assistance or to locate a qualified service agent in your area.

**⚠ WARNING**

**Jumping out control circuits or components can result in property damage, personal injury or death.**

- Service should only be performed by a qualified service technician using proper test equipment.
- Altering the water heater controls and/or wiring in any way could result in permanent damage to the controls or water heater and is not covered under the limited warranty.

Any bypass or alteration of the water heater controls and/or wiring will result in voiding the appliance warranty.









**FAULT AND ALERT MESSAGES**

Call the technical support phone number listed on the back cover for further technical assistance or to locate a qualified service agent in your area.

Possible Causes - Check/Repair	Displayed Fault/Alert Message
<ul style="list-style-type: none"> <li>• Using a manometer, ensure that gas supply pressure is above minimum requirement listed on heater's data plate and does not drop more than 1.5" W.C. when unit fires.</li> <li>• Ensure wire connections to gas valve are clean and tight.</li> <li>• Ensure wire connections to flame sensor are clean and tight.</li> <li>• Ensure wire connections to spark igniter are clean and tight.</li> <li>• Inspect flame sensor, clean/replace as needed.</li> <li>• Inspect spark igniter, realign igniter gap as needed.</li> <li>• Ensure adequate electrical ground to heater.</li> </ul>	<div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;"><b>Ignition Failure</b> 0 days 0 hr 0 min ago Error Code: B2-70</p> <p>Flame not detected. Clean flame rod. Check gas supply.</p> <p>Press the Advanced button for more information</p> <p style="text-align: center;"> <span style="border: 1px solid black; padding: 2px 10px;">BACK</span> <span style="border: 1px solid black; padding: 2px 10px;">ADVANCED</span> </p> </div>
<ul style="list-style-type: none"> <li>• Confirm that the CCB's pump contact function properly by detecting the 120V present or not at the recirculator after the flame icon shows up on UIM).</li> <li>• Confirm the flow switch mounted correctly ( the flow arrow pointing vertically upward) and function properly.</li> <li>• Confirm the recirculator is installed properly (flow pointing downward) and operate properly.</li> <li>• Check water flow blockage at the recirculator's impeller area and inside the secondary heat exchanger.</li> <li>• Flow switch malfunction, failed to "close" at water flowing. Replace flow switch.</li> </ul>	<div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;"><b>Flow Not Detected</b> 0 days 0 hr 0 min ago Error Code: 175-0</p> <p>Flow was not detected when in heating state.</p> <p>Press the Advanced button for more information</p> <p style="text-align: center;"> <span style="border: 1px solid black; padding: 2px 10px;">BACK</span> <span style="border: 1px solid black; padding: 2px 10px;">ADVANCED</span> </p> </div>
<p>Check the following:</p> <ul style="list-style-type: none"> <li>• The power supply connection to CPAM</li> <li>• The cable between CCB and CPAM</li> </ul>	<div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;"><b>Module Disconnected</b> 0 days 0 hr 0 min ago Error Code: 1C-101</p> <p>CCB is expecting a module attached to AIN communications and is not present.</p> <p>Press the Advanced button for more information.</p> <p style="text-align: center;"> <span style="border: 1px solid black; padding: 2px 10px;">BACK</span> <span style="border: 1px solid black; padding: 2px 10px;">ADVANCED</span> </p> </div>



Possible Causes - Check/Repair	Displayed Fault/Alert Message
<ul style="list-style-type: none"> <li>• If the Blocked Intake error occurs before blower runs, make sure the pressure switch connections are clean and tight. Check the pressure switch continuity/resistance. The switch should be closed (continuity/0 ohms). Replace the switch if it is open (no continuity).</li> <li>• If the Blocked Intake error occurs when blower is running, check for restrictions in intake pipe, including intake-air connection, outside termination, and inlet condensate drains (if installed).</li> <li>• Other possible causes: high wind conditions and excessive negative air pressure in building.</li> </ul>	<div data-bbox="917 180 1401 459" style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;"><b>Blocked Air Intake</b></p> <p style="text-align: center; font-size: small;">Fault occurred 2 mins ago</p> <div style="display: flex; justify-content: space-between;">  <div style="text-align: center;"> <p>Restriction in air intake. Check intake pipe and termination for blockage.</p> <p>Call a service professional: Your Company Name Here (press [DOWN] for more....)</p> </div>  </div> <div style="display: flex; justify-content: space-around; margin-top: 5px;"> <span>BACK</span> <span>ADVANCED</span> </div> </div>
<ul style="list-style-type: none"> <li>• Ensure that the wire connections to the upper temperature probe are clean and tight.</li> <li>• Using a thermometer, check the water temperature of the water heater.</li> <li>• Use a multi-meter and check for continuity between the two red wires of the upper temperature probe.</li> <li>• If the two red wires are open (no continuity) and water temperature is below 71°C (160°F), replace upper temperature probe.</li> <li>• If the water temperature exceeds 90°C (195°F), turn off the electric power and gas supply and call Tech Support for further instructions.</li> </ul>	<div data-bbox="917 569 1401 848" style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;"><b>High Temp Limit Exceeded</b></p> <p style="text-align: center; font-size: small;">0 days 0 hrs 0 mins ago Error Code: A5-401</p> <div style="display: flex; justify-content: space-between;">  <div style="text-align: center;"> <p>Energy Cut Off has shut off water heater due to high tank temperature.</p> <p>Press the Advanced button for</p> </div>  </div> <div style="display: flex; justify-content: space-around; margin-top: 5px;"> <span>BACK</span> <span>ADVANCED</span> </div> </div>
<ul style="list-style-type: none"> <li>• Flow switch should be remain “open” during standby.</li> <li>• Confirm the switch is set at “Open” (factory default).</li> <li>• Confirm the switch is installed correctly with flow arrow pointing upward vertically.</li> <li>• Remove &amp; inspect the flow switch’s vane free from any debris.</li> <li>• Replace the switch if malfunction detected.</li> </ul>	<div data-bbox="917 947 1401 1226" style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;"><b>Flow Switch Stuck Closed</b></p> <p style="text-align: center; font-size: small;">0 days 0 hrs 0 mins ago Error Code: D6-8</p> <div style="display: flex; justify-content: space-between;">  <div style="text-align: center;"> <p>Flow switch should be open when heater is in standby state.</p> </div>  </div> <div style="display: flex; justify-content: space-around; margin-top: 5px;"> <span>ACCEPT</span> <span>BACK</span> <span>ADVANCED</span> </div> </div>

# MAINTENANCE

## GENERAL

Keep water heater area clear and free from combustible materials, gasoline, and other flammable vapors and liquids. See *Locating the Water Heater* (page 11).

Water heater maintenance includes periodic tank flushing and cleaning, and removal of lime scale. The water heater should be inspected and adjusted to maintain proper combustion. See *Initial Start Up* (page 48). A periodic inspection of the venting system should be made. Where used, water circulating pump(s) should be oiled according to the pump manufacturers recommendations.

## PRECAUTIONS

### ⚠ CAUTION

**Do not operate the water heater if it has been exposed to or exhibits the following:**

- Exposed to flooding or water damage
- External damage.
- Firing without water.
- Sooting.

Do not operate the water heater until all corrective steps have been made by a qualified service technician.

Never operate the water heater without first being certain it is filled with water and a properly sized and rated Temperature-Pressure Relief Valve is installed in the relief valve opening on the water heater. See *Temperature-Pressure Relief Valve* (page 15).

### ⚠ WARNING

**Explosion Hazard**

- Overheated water can cause water tank explosion.
- Properly sized temperature and pressure relief valve must be installed in the opening provided.

If overheating occur or the gas supply fail to shut off, turn off the Main Gas Shutoff valve. See *Figure 29* (page 30).

## MAINTENANCE SCHEDULE

Table 17. Maintenance Schedule			
Component	Operation	Interval	Reference
Tank	Drain and Flush	Every 6 Months	See <i>Draining and Flushing</i> .
Tank	Lime Scale Removal (Water Less Than 25 Grains Hard)	Not Required	N/A
Tank	Lime Scale Removal (Water Greater Than 25 Grains Hard)	Annually	See <i>Lime Scale Removal</i> (page 59).
Burner Flames	Inspection	Every 3 Months	See <i>Burner Flame Inspection</i> (page 60).
Burner	Inspection/Cleaning	As Needed	Contact qualified agency or professional.
Moving Parts	Lubrication	Not Required	N/A
Powered Anodes	Inspection/Cleaning	Annually	See <i>Powered Anodes Maintenance</i> (page 60).
T&P Valve	Test Operation	Semi Annually	See <i>Temperature-Pressure Relief Valve</i> (page 15).
Vent System	Inspection	Annually	See <i>Vent System Maintenance</i> (page 61).

Table 17. Maintenance Schedule			
Component	Operation	Interval	Reference
Condensate Neutralization	Inspection	Annually	See manual for the condensate neutralization kit.
Condensate Collection	Cleaning	Annually	See <i>Vent System Maintenance</i> (page 61).

## DRAINING AND FLUSHING

It is recommended that the water heater storage tank be drained and flushed every 6 months to reduce sediment buildup. The water heater should be drained if being shut down during freezing temperatures. See *Features and Components* (page 8) for the location of the water heater components described below.

### ⚠ DANGER

- Burn hazard.
- Hot water discharge.
- Keep hands clear of drain valve discharge.

### To drain the water heater storage tank:

1. Turn the Enable/Disable switch located on the front of the heater to the Disabled position.
2. Turn off the electrical supply to the water heater.
3. Turn off the gas supply at the Main Gas Shutoff Valve if the water heater is going to be shut down for an extended period.
4. Ensure the cold water inlet valve is open.
5. Open a nearby hot water faucet and let the water run until the water is no longer hot.
6. Connect a hose to the water heater drain valve and terminate it to an adequate drain.
7. Close the cold water inlet valve.
8. Open the water heater drain valve and allow all the water to drain from the storage tank.
9. Close the water heater drain valve when all water in the storage tank has drained.
10. Close the hot water faucet opened in Step 4.
11. If the water heater is going to be shut down for an extended period, the drain valve should be left open.

### To Flush the tank perform the following steps:

1. Turn the Enable/Disable switch located on the front of the heater to the Disabled position.
2. Turn off the electrical supply to the water heater.
3. Ensure the cold water inlet valve is open.
4. Open a nearby hot water faucet and let the water run until the water is no longer hot. Then close the hot water faucet.
5. Connect a hose to the drain valve and terminate it to an adequate drain.

6. Ensure the drain hose is secured before and during the entire flushing procedure. Flushing is performed with system water pressure applied to the water heater.
7. Open the water heater drain valve to flush the storage tank.
8. Flush the water heater storage tank to remove sediment and allow the water to flow until it runs clean.
9. Close the water heater drain valve when flushing is completed.
10. Remove the drain hose.
11. Fill the water heater. See *Filling the Water Heater* (page 48).
12. Turn on the electrical supply to place the water heater back in operation.
13. Allow the water heater to complete several heating cycles to ensure it is operating properly.

### SEDIMENT REMOVAL

Waterborne impurities consist of the particles of soil and sand which settle out and form a layer of sediment on the bottom of the tank.

For convenience, sediment removal and lime scale removal should be performed at the same time.

### LIME SCALE REMOVAL

When water is heated dissolved minerals in the water such as calcium and magnesium carbonate (lime scale) become less soluble. As the water temperature rises these minerals will precipitate or “fall out” of solution.

The amount of lime scale released from water is in direct proportion to water temperature and usage. The higher the water temperature or water usage, the more lime deposits are dropped out of the water.

Water hardness also affects lime scale accumulation. With the temperature and usage being the same, hard water will release more lime scale than softer water.

Lime scale reduces heating efficiency as it accumulates inside a water heater. Heating transfer surfaces become coated with lime scale deposits which increases fuel costs to operate the water heater. Lime scale deposits can also cause rumbling and pounding noises as air molecules trapped in the lime scale escape when heated. Lime scale accumulation also reduces the life span of water heaters. For these reasons a regular schedule for deliming should be set up.

The depth of lime accumulation in the bottom of the water heater should be measured periodically. Inspect by removing the cleanout cover once every 6 months at first. Deliming maintenance should then be performed based on the time it takes for 1 inch (2.5 cm) of lime to accumulate in the bottom of the water heater.

Sediment and lime scale removal may be accomplished manually through the cleanout opening furnished on the water heater. See *Figure 38*.

### MANUAL LIME SCALE REMOVAL

**Note:** Contact your local distributor or call the parts department phone number on the back cover of this manual to order a new cleanout gasket. Have the new gasket available before removing the cleanout cover.

The cleanout opening is shown in Figure 55. To remove lime scale manually through the cleanout opening proceed as follows:

1. Turn off the electrical supply to the water heater.
2. The water heater must be drained. See *Draining and Flushing* (page 58). Follow the instructions on how to drain the water heater.
3. Remove outer cleanout access panel from lower side of the water heater jacket.
4. Remove the cleanout cover from cleanout opening.
5. Remove lime, scale and/or sediment using care not to damage the glass-lining.
6. Install a new cleanout gasket if required.
7. Reinstall the cleanout cover. Be sure to draw plate up tight by tightening screws securely.
8. Close the water heater drain valve.
9. Fill the water heater. See *Filling the Water Heater* (page 48).
10. Turn on the electrical supply to place the water heater back in operation. See *Initial Start Up* (page 48).
11. Allow the water heater to complete several heating cycles to ensure it is operating properly.
12. Check for water leakage.
13. Reinstall the cleanout access panel.

### CHEMICAL LIME SCALE REMOVAL

To dissolve and remove more stubborn lime scale deposits, UN-LIME® Professional Delimer should be used.

UN-LIME® Professional Delimer is an easy to handle patented food grade acid formulated specifically for lime scale removal from all types of water using equipment. Hydrochloric base acids must not be used to delime the water heaters covered in this manual.

Follow the instructions on the UN-LIME® to delime the water heater.

**Note:** Call the parts department phone number on the back cover of this manual to order UN-LIME® Professional Delimer. See *Table 18* for part numbers.

Part Number	Description
100110459	4 - 1 gallon (case)
100110460	1 - 5 gallon

## BURNER FLAME INSPECTION

Check main burner every three months for proper flame characteristics. You can see the burner flame through the sight glass on top of the burner plate. To access the sight glass, you must remove the plastic cover.




Figure 36. Location of Sight Glass

The main burner should display the following characteristics:

- Provide complete combustion of gas.
- Cause rapid ignition and carry over of flame across entire burner.
- Give reasonably quiet operation during initial ignition, operation and extinction.
- Cause no excessive lifting of flame from burner ports. See *Figure 36*.




Figure 37. Normal and Abnormal Burner Flames

If the preceding burner characteristics are not evident, check for accumulation of lint or other foreign material that restricts or blocks the air intake fitting or air intake terminal.

To ensure continued good performance, keep the area around the water heater clean and free from lint and debris. Sweep the floor around the water heater regularly. This will reduce the dust and dirt which can enter the burner and heat exchanger, causing improper combustion and sooting.

If the air intake fitting and air intake terminal are clear and the burner continues to exhibit abnormal flames, contact a qualified service agency or have a qualified service professional inspect and clean the burner.

## POWERED ANODES MAINTENANCE

To insure a long, trouble-free operating life, the water heaters covered in this manual are factory equipped with a powered anode system. The anode rods are of a permanent design and do not need replacing unless damaged. Inspection and cleaning should be performed once a year.

1. Follow the instructions in drain the water heater in *Draining and Flushing* (page 58) first.
2. Remove the powered anodes from the water heater by loosening the 3/4" NPT bushing that forms the top of the anodes. Do not disassemble the retaining nut and wire terminal from the top while installed in the water heater. The anode's electrode may fall inside the tank.
3. Remove the entire anode rod from the water heater prior to inspection.
4. Clean the anode rods with a soft cloth and reinstall.
5. Follow the instructions for filling the water heater in *Filling the Water Heater* (page 48).

## DRAIN VALVE AND ACCESS PANELS

The water heaters covered in this manual are equipped with a drain valve. See *Features and Components* (page 8) for location. The water heaters covered in this manual are also equipped with a cleanout opening for sediment and lime scale removal. See *Figure 38* (page 60).





Figure 38. Cleanout Access

## TEMPERATURE-PRESSURE RELIEF VALVE TEST




It is recommended that the Temperature-Pressure Relief Valve should be checked to ensure that it is in operating condition every 6 months.

When checking the Temperature-Pressure Relief Valve operation, make sure that (1) no one is in front of or around the outlet of the Temperature-Pressure Relief Valve discharge line, and (2) that the water discharge will not cause any property damage, as the water may be extremely hot. Use care when operating valve as the valve may be hot.

To check the relief valve, lift the lever at the end of the valve several times. See **Figure 39**. The valve should seat properly and operate freely.

If after manually operating the valve, it fails to completely reset and continues to release water, immediately close the cold water inlet to the water heater and drain the water heater. See **Draining and Flushing** (page 58). Replace the Temperature-Pressure Relief Valve with a properly rated/sized new one See **Temperature-Pressure Relief Valve** (page 15) for instructions on replacement.



**Figure 39. Testing the T&P Relief Valve**


If the Temperature-Pressure Relief Valve on the water heater weeps or discharges periodically, this may be due to thermal expansion.

**Note:** Excessive water pressure is the most common cause of Temperature-Pressure Relief Valve leakage. Excessive

water system pressure is most often caused by “thermal expansion” in a “closed system.” See **Closed Water Systems** (page 14) and **Temperature-Pressure Relief Valve** (page 15). The Temperature-Pressure Relief Valve is not intended for the constant relief of thermal expansion.

Temperature-Pressure Relief Valve leakage due to pressure build up in a closed system that does not have a thermal expansion tank installed is not covered under the limited warranty. Thermal expansion tanks must be installed on all closed water systems.

**DO NOT PLUG THE TEMPERATURE-PRESSURE RELIEF VALVE OPENING. THIS CAN CAUSE PROPERTY DAMAGE, SERIOUS INJURY OR DEATH.**



## VENT SYSTEM MAINTENANCE

Examine the vent system once a year. Points of inspection are as follows:

1. Check for obstructions and/or deterioration of the intake air and/or vent piping and the intake air and vent terminations. Replace immediately where needed.
2. The debris screens in the intake air and vent terminations should be cleaned of foreign material and soot. See **Figure 19** (page 25).

**Note:** Do not reach inside the vent termination when the heater is in operation.

3. Check all vent system connections for leakage and repair or reseal as necessary.

# DIAGRAMS

## CCB - CENTRAL CONTROL BOARD LAYOUT




Figure 40. CCB (Central Control Board)

# WIRING DIAGRAM




Figure 41. Wiring Diagram

## CIRCULATION PUMP WIRING DIAGRAMS




Figure 42. Circulating Pump Wiring Diagram Storage Tank or Building Recirculation




Figure 43. Circulating Pump Wiring Diagram - Dish-Washer Loop with Toggle Switch



## WATER PIPING DIAGRAMS

Before installation of water piping review the following:



1. See *Mixing Valves* (page 13).
2. See *Dish-washing Machines* (page 14).
3. See *Temperature-Pressure Relief Valve* (page 15).
4. See *Closed Water Systems* (page 14) and *Temperature-Pressure Relief Valve* (page 15).
5. See *Water Line Connections* (page 58).
6. If a pump is being installed between a water heater and storage tank or on a building recirculation loop wire according to *Figure 42* (page 64).
7. If a pump is being installed in a recirculation loop between the water heater and a commercial dishwasher wire according to *Figure 43* (page 64).

### ONE WATER HEATER, SINGLE TEMPERATURE WITH BUILDING RECIRCULATION

**WARNING:** THIS DRAWING SHOWS SUGGESTED PIPING CONFIGURATION AND OTHER DEVICES; CHECK WITH LOCAL CODES AND ORDINANCES FOR ADDITIONAL REQUIREMENTS.

ANY MATERIAL, COMPONENT, OR VENDOR CHANGE MUST HAVE PRIOR APPROVAL BY THE APPLICABLE PRODUCT ENGINEERING DEPARTMENT.

#### Legend



#### NOTES:

1. Preferred piping method.
2. The temperature and pressure relief valve setting shall not exceed pressure rating of any component in the system.
3. Service valves are shown for servicing unit. However, local codes shall govern their usage.

# WATER PIPING DIAGRAMS

Before installation of water piping review the following:

1. See *Mixing Valves* (page 13).
2. See *Dish-washing Machines* (page 14).
3. See *Temperature-Pressure Relief Valve* (page 15).
4. See *Closed Water Systems* (page 14) and *Temperature-Pressure Relief Valve* (page 15).



5. See *Water Line Connections* (page 58).
6. If a pump is being installed between a water heater and storage tank or on a building recirculation loop wire according to *Figure 42* (page 64).
7. If a pump is being installed in a recirculation loop between the water heater and a commercial dishwasher wire according to *Figure 43* (page 64).

## ONE WATER HEATER, TWO TEMPERATURES, WITH HIGH-TEMPERATURE LOOP RECIRCULATION

**WARNING:** THIS DRAWING SHOWS SUGGESTED PIPING CONFIGURATION AND OTHER DEVICES; CHECK WITH LOCAL CODES AND ORDINANCES FOR ADDITIONAL REQUIREMENTS.

ANY MATERIAL, COMPONENT, OR VENDOR CHANGE MUST HAVE PRIOR APPROVAL BY THE APPLICABLE PRODUCT ENGINEERING DEPARTMENT.

### Legend



### NOTES:

1. Preferred piping method.
2. The temperature and pressure relief valve setting shall not exceed pressure rating of any component in the system.
3. Service valves are shown for servicing unit. However, local codes shall govern their usage.

# WATER PIPING DIAGRAMS


Before installation of water piping review the following:

1. See *Mixing Valves* (page 13).
2. See *Dish-washing Machines* (page 14).
3. See *Temperature-Pressure Relief Valve* (page 15).
4. See *Closed Water Systems* (page 14) and *Temperature-Pressure Relief Valve* (page 15).

5. See *Water Line Connections* (page 58).
6. If a pump is being installed between a water heater and storage tank or on a building recirculation loop wire according to *Figure 42* (page 64).
7. If a pump is being installed in a recirculation loop between the water heater and a commercial dishwasher wire according to *Figure 43* (page 64).


## ONE WATER HEATER, SINGLE TEMPERATURE, WITH HORIZONTAL STORAGE TANK, FORCED RECIRCULATION, WITH BUILDING RECIRCULATION

### Legend



**WARNING:** THIS DRAWING SHOWS SUGGESTED PIPING CONFIGURATION AND OTHER DEVICES; CHECK WITH LOCAL CODES AND ORDINANCES FOR ADDITIONAL REQUIREMENTS.

ANY MATERIAL, COMPONENT, OR VENDOR CHANGE MUST HAVE PRIOR APPROVAL BY THE APPLICABLE PRODUCT ENGINEERING DEPARTMENT.



### NOTES:

1. Preferred piping method.
2. The temperature and pressure relief valve setting shall not exceed pressure rating of any component in the system.
3. Service valves are shown for servicing unit. However, local codes shall govern their usage.

# WATER PIPING DIAGRAMS


Before installation of water piping review the following:

1. See *Mixing Valves* (page 13).
2. See *Dish-washing Machines* (page 14).
3. See *Temperature-Pressure Relief Valve* (page 15).
4. See *Closed Water Systems* (page 14) and *Temperature-Pressure Relief Valve* (page 15).

5. See *Water Line Connections* (page 58).
6. If a pump is being installed between a water heater and storage tank or on a building recirculation loop wire according to *Figure 42* (page 64).
7. If a pump is being installed in a recirculation loop between the water heater and a commercial dishwasher wire according to *Figure 43* (page 64).


## ONE WATER HEATER, SINGLE TEMPERATURE, WITH HORIZONTAL STORAGE TANK, FORCED RECIRCULATION, WITH BUILDING RECIRCULATION

### Legend



**WARNING:** THIS DRAWING SHOWS SUGGESTED PIPING CONFIGURATION AND OTHER DEVICES; CHECK WITH LOCAL CODES AND ORDINANCES FOR ADDITIONAL REQUIREMENTS.

ANY MATERIAL, COMPONENT, OR VENDOR CHANGE MUST HAVE PRIOR APPROVAL BY THE APPLICABLE PRODUCT ENGINEERING DEPARTMENT.



### NOTES:

1. Preferred piping method.
2. The temperature and pressure relief valve setting shall not exceed pressure rating of any component in the system.
3. Service valves are shown for servicing unit. However, local codes shall govern their usage.

# WATER PIPING DIAGRAMS

Before installation of water piping review the following:



1. See *Mixing Valves* (page 13).
2. See *Dish-washing Machines* (page 14).
3. See *Temperature-Pressure Relief Valve* (page 15).
4. See *Closed Water Systems* (page 14) and *Temperature-Pressure Relief Valve* (page 15).
5. See *Water Line Connections* (page 58).
6. If a pump is being installed between a water heater and storage tank or on a building recirculation loop wire according to *Figure 42* (page 64).
7. If a pump is being installed in a recirculation loop between the water heater and a commercial dishwasher wire according to *Figure 43* (page 64).

## TWO WATER HEATERS, SINGLE TEMPERATURE, WITH BUILDING RECIRCULATION

**WARNING:** THIS DRAWING SHOWS SUGGESTED PIPING CONFIGURATION AND OTHER DEVICES; CHECK WITH LOCAL CODES AND ORDINANCES FOR ADDITIONAL REQUIREMENTS.

ANY MATERIAL, COMPONENT, OR VENDOR CHANGE MUST HAVE PRIOR APPROVAL BY THE APPLICABLE PRODUCT ENGINEERING DEPARTMENT.

### Legend



### NOTES:

1. Preferred piping method.
2. The temperature and pressure relief valve setting shall not exceed pressure rating of any component in the system.
3. Service valves are shown for servicing unit. However, local codes shall govern their usage.

# WATER PIPING DIAGRAMS

Before installation of water piping review the following:



1. See **Mixing Valves** (page 13).
2. See **Dish-washing Machines** (page 14).
3. See **Temperature-Pressure Relief Valve** (page 15).
4. See **Closed Water Systems** (page 14) and **Temperature-Pressure Relief Valve** (page 15).
5. See **Water Line Connections** (page 58).
6. If a pump is being installed between a water heater and storage tank or on a building recirculation loop wire according to **Figure 42** (page 64).
7. If a pump is being installed in a recirculation loop between the water heater and a commercial dishwasher wire according to **Figure 43** (page 64).

## THREE WATER HEATERS, SINGLE TEMPERATURE WITH BUILDING RECIRCULATION

**WARNING:** THIS DRAWING SHOWS SUGGESTED PIPING CONFIGURATION AND OTHER DEVICES; CHECK WITH LOCAL CODES AND ORDINANCES FOR ADDITIONAL REQUIREMENTS.

ANY MATERIAL, COMPONENT, OR VENDOR CHANGE MUST HAVE PRIOR APPROVAL BY THE APPLICABLE PRODUCT ENGINEERING DEPARTMENT.

### Legend



### NOTES:

1. Preferred piping method.
2. The temperature and pressure relief valve setting shall not exceed pressure rating of any component in the system.
3. Service valves are shown for servicing unit. However, local codes shall govern their usage.



